

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION
P.O. Box 2088

Santa Fe, New Mexico 87504-2088

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO.	3004507805
5. Indicate Type of Lease	STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.	SF078109
7. Lease Name or Unit Agreement Name	Gallegos Canyon Unit Com G
8. Well No.	179
9. Pool name or Wildcat	Basin Dakota
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	2. Name of Operator Amoco Production Company	Attention: Julie Acevedo
3. Address of Operator P.O. Box 800 Denver CO 80201	4. Well Location Unit Letter K : 1460 Feet From The South Line and 2494 Feet From The West Line Section 26 Township 29N Range 12W NMPM San Juan County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.)		

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: Bradenhead Repair ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Amoco intends to perform the attached workover procedure to eliminate bradenhead pressure.

verbal approval received 1-25-93 from Enni Bunk Amoco Julie Acevedo (AMC)

If you have any questions please call Julie Acevedo at 303-830-6003.

RECEIVED
FEB 1 1993
OIL CON. DIV.
DIST 3

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Julie Acevedo TITLE Sr Staff Assistant DATE 01-25-1993
TYPE OR PRINT NAME Julie Acevedo TELEPHONE NO. (303) 830-6003

(This space for State Use)

APPROVED BY Original Signed by CHARLES GHOLSON DEPUTY OIL & GAS INSPECTOR, DIST. #3 DATE FEB 1 1993
CONDITIONS OF APPROVAL, IF ANY:

Workover Procedure
Gallegos Canyon Unit Com G #179
Sec.26-T29N-R12W
San Juan County, NM

1. Contact Federal or State agency prior to starting repair work.
2. Catch gas and/or water sample off of bradenhead and casing, and have analyzed.
3. Install and/or test anchors on location.
4. MIRUSU. Check and record tubing, casing and bradenhead pressures.
5. Blow down well and kill well, if necessary, with 2% KCL water.
6. ND wellhead. NU and pressure test BOP's.
7. TIH and tag PBTD, check for fill. Trip and tally out of hole with tubing, checking condition of tubing.
8. TIH with bit and scraper to top of perforations. A seating nipple and standing valve may be run in order to pressure test tubing. TOH.
9. TIH with RBP and packer. Set RBP 50-100 ft. above perforations. TOH one joint and set packer. Pressure test RBP to 1500 psi.
10. Pressure test casing above packer. Isolate leak, if any, by moving packer up the hole and repeating pressure test.

NOTE: If this can not be accomplished, contact Emily Miller in Denver at (303) 830-4214. If no leak is found, it may be necessary to perforate the casing below surface casing depth or above the top of cement in order to circulate cement to surface.
11. Establish injection rate into leak, if found, and attempt to circulate to surface.
12. Release packer, spot sand on RBP and TOH with packer.
13. Run, if necessary, a CBL and CCL to determine cement top.
14. Perforate casing above cement top, if necessary, with 4 JSPF and circulate dye to determine cement volume.

15. Depending on depth of hole and circulating pressure, a packer or cement retainer may be needed.
16. Mix and pump sufficient cement (Class B or equivalent, with a setting time of 2 hours) to circulate to surface. Shut bradenhead valve and attempt to walk squeeze to obtain a 1000 psi squeeze pressure. WOC.
17. TIH with bit and scraper and drill out cement. Pressure test casing to 1000 psi. TOH with bit and scraper.
18. TIH with retrieving head for RBP. Circulate sand off of RBP and TOH with RBP.
19. TIH with sawtooth collar and/or bailer and clean out hole to PBTD, if fill was found in step 7. TOH.
20. TIH with production string (1/2 mule shoe on bottom and seating nipple one joint off bottom) and land tubing to original depth. NDBOP. NU wellhead.
21. Swab well in and put on production.
22. RDMOSU.

GALLEGOS CANYON UNIT COM G 179
LOCATION - K26-29N-12W
SINGLE DK
ORIG. COMPLETION - 11/64
LAST FILE UPDATE - 9/92 BY CSW

BOT OF 8.625 IN OD CSA 370
24 LB/FT. J-55 CASING, W/300 SKS
CTR TO SURFACE
PICTURED CLIFFS @1440
MESA VERDE @2985
GALLUP @5082
DAROTA @6026

DV TOOL @4261

DK-4SPF PERF 5951-5963]

BOT OF 2.375 IN OD TBG AT 5993

DK-4SPE PERF 6049-6053
6054-6060]

PBTD AT 6073 FT.

TOTAL DEPTH 6110 FT.

BOT OF 4.5 IN OD CSA 6110
10.5 LB/FT. J-55 CASING
W/1500 SKS

FILENAME:
04507805