

NO. OF COPIES RECEIVED	7
DISTRIBUTION	
SANTA FE	1
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	5

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name Gerard "A"
9. Well No. #1
10. Field and Pool, or Wildcat Basin Dakota
12. County San Juan

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-
2. Name of Operator Aztec Oil & Gas Company
3. Address of Operator P. O. Drawer 570, Farmington, New Mexico
4. Location of Well UNIT LETTER <u>E</u> <u>1750</u> FEET FROM THE <u>North</u> LINE AND <u>890</u> FEET FROM THE <u>West</u> LINE, SECTION <u>21</u> TOWNSHIP <u>29N</u> RANGE <u>13W</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 5252' GR

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIATION WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

PROPOSE TO:

1. Move on location and rig up.
2. Pull and lay down rods and pump.
3. Pull tubing.
4. Spot 60 sack cement plug across Dakota. *from 5650'*
5. Take stretch, shoot off casing and retrieve same.
6. Spot 50 sack plug on stub.
7. Spot 50 sack plug at base of surface pipe.
8. Spot 15 sack plug at surface.
9. Install dry hole marker.

*Plug from 1000' to 880' inside and outside of 4 1/2" casing.*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *A. R. Kendrick* TITLE District Production Manager DATE May 11, 1977

Original Signed by A. R. Kendrick  
APPROVED BY \_\_\_\_\_

TITLE SUPERVISOR DIST. M.

DATE MAY 12 1977

CONDITIONS OF APPROVAL, IF ANY: