

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65


5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL <input type="checkbox"/> WELL <input type="checkbox"/> GAS <input type="checkbox"/> WELL <input type="checkbox"/> OTHER- DRY HOLE	7. Unit Agreement Name
2. Name of Operator ELVIS L. ROBERTS <i>% Brock, Whitest & Galley</i>	8. Farm or Lease Name WADE
3. Address of Operator <i>P.O. Box 10305, Lubbock, Texas 79408</i>	9. Well No. 1
4. Location of Well UNIT LETTER -B- 850 FEET FROM THE NORTH LINE AND 1750 FEET FROM THE EAST LINE, SECTION 21 TOWNSHIP 29N RANGE 11W NMPM.	10. Field and Pool, or Wildcat Aztec-Fruitland
15. Elevation (Show whether DF, RT, GR, etc.)	12. County San Juan

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOBS <input type="checkbox"/> OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including the estimated date of starting any proposed work) SEE RULE 1703.

- 1). Set a plug from 1476' to 1250' using 30 sacks.
- 2). Attempt casing salvage.
- 3). If casing is pulled from below 600':
 - A. Set a plug from 600' to 500' using 28 sacks.
 - B. Shut down 6 hours minimum with accelerated cement and 12 hours with neat cement. Tag cement plug. If plug is below 550' replug to 500'.
 - C. Set a plug from 175' to 75' using 28 sacks.
- 4). If casing not pulled from below 600', or 175' respectively:
 - A. Perforate @ 600' and set a 100' plug inside and outside the 5 1/4" casing using 28 sacks, squeezing 14 sacks through the perforations.
 - B. Follow step 3B.
 - C. Perforate @ 175' and set a 100' plug inside and outside the 5 1/4" casing using 28 sacks, squeezing 14 sacks through the perforations.
- 5). Set the required marker and stabilize all casing at the surface.
- 6). Remove all junk from the location.
- 7). Restore surface location to pre-existing conditions.



ALL WORK TO BE DONE UNDER THE DIRECT SUPERVISION OF THE OIL CONSERVATION DIVISION.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cham L. Wata Authorized Attorney and Agent for the Estate of Elvis L. Roberts, Deceased DATE 6/7/78

APPROVED BY AR Hendrick TITLE SUPERVISOR DIST. #3 DATE JUN 9 1978

CONDITIONS OF APPROVAL, IF ANY:

FIELD WORK SHALL BE COMPLETED ON OR BEFORE AUGUST 15, 1978