

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

F. 14-20-603-2199

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

Navajo

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Northwest Cha Cha 16

9. WELL NO.

14-18

10. FIELD AND POOL, OR WILDCAT

Cha Cha Gallup

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 16, Twp. 29N,
Rge. 14W

12. COUNTY OR PARISH

San Juan

13. STATE

N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT--" for such proposals.)

1. ☐ OIL
WELL ☒ GAS
WELL ☐ OTHER

2. NAME OF OPERATOR

Suburban Propane Gas Corp.

3. ADDRESS OF OPERATOR

P. O. Box 1980, Farmington, New Mexico 87401

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

250' FSL, 800' FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

KB 5190 DF 5189 G 5178

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL



ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)*

1. Rigged up, and ran 1 1/2" tubing to 4600. Spot first plug with 150 feet of cement.
2. Spot second plug at 2300 with 200 feet of cement M.V.
3. If we can cut or pull casing at 950 or below spot third plug at 950 to 800 with 150 feet of cement P.C.
4. Spot fourth plug at 600 to 450 with 150 feet of cement Farm.
5. Spot fifth plug at 250 to 200 with 50 feet of cement O.A.
6. Spot top plug with 10 sacks of cement.
7. If can't cut or pull casing below 500 feet set plug three above and perf. at 580 with two shots. Cement 150 feet cement inside and outside.
8. Perf. at 250 two shots. Cement 50 feet of cement inside and outside.
9. Rig down and clean up location. Cut off below ground.



18. I hereby certify that the foregoing is true and correct

SIGNED: George H. Wells

TITLE

Superintendent

Rocky Mountain Area

U.S. GEOLOGICAL SURVEY

DATE 1-24-79

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

Obal