

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION


Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Federal Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A PERMANENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Temporarily Abandoned	7. Unit Agreement Name
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name Herrin
3. Address of Operator Box 990, Farmington, New Mexico 87401	9. Well No. 1 (P&A)
4. Location of Well UNIT LETTER L , 1750 FEET FROM THE South LINE AND 990 FEET FROM THE West LINE, SECTION 13 TOWNSHIP 29N RANGE 10W NMPM.	10. Field and Pool, or Wildcat Aztec Pictured Cliffs
15. Elevation (Show whether DF, RT, GR, etc.) 5255' GL	12. County San Juan



16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/> REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

On 9-28-61 this well was temporarily abandoned by ~~spotting~~ spotting a 50 sack cement plug from 2195' to 2270'. (38' of open hole and 75' in 7" casing).

Due to non-production it is planned to plug and abandoned this well in the following manner:

Determine free point of 7" casing by stretch. Shoot casing off above free point and spot a 30 sack cement plug by displacing down the casing.

Pull 7" casing. Place a 25 sack cement plug across base of surface casing.

Place a 10 sack cement plug at surface, install a 4' x 4" dry hole marker and clean location.

NOTE: If free point is above the top of the Ojo Alamo (1114') perforate at 1216' (base of the Ojo Alamo) before shooting casing off and spot a 50 sack cement plug inside 7" casing at 1216' and pressure displace through perforations about 20 sacks.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED: Original Signed F. H. WOOD TITLE: Petroleum Engineer DATE: 7-24-70

APPROVED BY: [Signature] PETROLEUM ENGINEER DIST. NO. 9 DATE: 7-24-70
CONDITIONS OF APPROVAL, IF ANY: