

COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

3-NMOCC 1-File

NEW MEXICO OIL CONSERVATION COMMISSION


Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/> 5. State Oil & Gas Lease No. E 7673
1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- 2. Name of Operator Dugan Production Corp. 3. Address of Operator Box 234, Farmington, NM 87401 4. Location of Well UNIT LETTER J 1750 FEET FROM THE South LINE AND 1820 FEET FROM THE East LINE, SECTION 2 TOWNSHIP 29N RANGE 14W NMPM.	7. Unit Agreement Name 8. Farm or Lease Name Com 9. Well No. 1 10. Field and Pool, or Wildcat Basin Dakota	
15. Elevation (Show whether DF, RT, GR, etc.) 5516 GR	12. County San Juan	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plan to pull tubing, set bridge plug above Dakota Fm at 5000', check casing for hole, if hole is found, plan to squeeze hole with 200 sx cement or until hole squeezed off, drill out cement and bridge plug, cleanout to 5850', run tubing with packer, swab well in, acidize if necessary and put well on production.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Thomas A. Dugan</u>	TITLE <u>Petroleum Engineer</u>	DATE <u>11-2-78</u>
APPROVED BY <u>AK Kendrick</u>	TITLE <u>Assistant Engineer</u>	DATE <u>NOV 6 '78</u>

CONDITIONS OF APPROVAL, IF ANY: