

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

5a. Indicate Type of Lease  
State ☐ Fee ☒  
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name Martin
3. Address of Operator P. O. Box 289, Farmington, New Mexico 87401	9. Well No. 4
4. Location of Well UNIT LETTER _____ 990 FEET FROM THE North LINE AND 1650 FEET FROM THE West LINE, SECTION 3 TOWNSHIP 29 RANGE 11 NMPM.	10. Field and Pool, or Wildcat Aztec P.C.
15. Elevation (Show whether DF, RT, GR, etc.) 5740' GR	12. County San Juan

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Recommended Procedure to Plug and Abandon:

- (1) Pull 1" tubing and run 2 3/8" work string.
- (2) Spot a 25 sx (29.5 cu. ft.) cement plug to fill from TD to 1860'.
- (3) Perforate 4 squeeze holes 50' below the base of the Ojo Alamo @887'. Spot a 40 sc (47.2 cu. ft.) cement plug from 720' to 887'. Pressure displace 18 sx into the squeeze holes.
- (4) Perforate 4 squeeze holes 50' below the base of the surface pipe @190'. Spot a 35 sx (41.3 cu. ft.) cement plug from 90' to 190'. Pressure displace 24 sx into the squeeze holes.
- (5) Spot a 10 sx (11.8 cu. ft.) surface plug and install dry hole marker.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Loren W. Fethergill Sr. TITLE Production Engineer DATE 8-25-81

APPROVED BY Original Signed by FRANK T. CHAVEZ TITLE SUPERVISOR DISTRICT # 3 DATE AUG 27 1981

CONDITIONS OF APPROVAL, IF ANY: