

NO. OF COPIES RECEIVED	4
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	2

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
~~XXXXXX~~ **FED.** ~~XXXXXX~~

5. ~~XXXXXX~~ Gas Lease No.
SF-078144

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Beta Development Co.	8. Farm or Lease Name Fogelson 26
3. Address of Operator 125 Petr. Club Plaza, Farmington, New Mexico 87401	9. Well No. 1
4. Location of Well UNIT LETTER P , 1050 FEET FROM THE South LINE AND 1000 FEET FROM THE East LINE, SECTION 26 TOWNSHIP 30N RANGE 11W NMPM.	10. Field and Pool, or Wildcat Basin Dakota
15. Elevation (Show whether DF, RT, GR, etc.) 5899' G.L.	12. County San Juan


16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to repair well as follows:

Rig up workover unit, circ. out drlg. mud. Set Baker Model "N" bridge plug in 4 1/2" csg. opposite Greenhorn section @ approx. 6600'. GIH w/4 1/2" packer on 2-3/8" tbg & find top holes in csg. Set packer above all holes, pressure up back side of tbg. to 2000# to check all csg back to surface. POH. Pick up drillable cement retainer, GIH w/tbg., set retainer above all csg holes; squeeze w/350 sx 50-50 Pozmix Class "C" Cement - 4% gel, or until pressure is 2000#. WOC 10 hrs. Drill out retainer w/3-7/8" bit on tbg, drill and CO to bridge plug. Pressure test all csg to 2000#, repeat squeeze if necessary. Drill out bridge plug, CO to T.D. Land tbg., swab well in.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original signed by
D. E. BAXTER

SIGNED _____ TITLE **Superintendent** DATE **Feb. 10, 1969**

APPROVED BY *[Signature]* TITLE *[Signature]* DATE *2-11-69*

CONDITIONS OF APPROVAL, IF ANY: