



B.M.N.S. COMPANY

WAGGONER #1

K-29-30N-12W



BEFORE EXAMINER STARTS  
OIL CONSERVATION DIVISION  
EXHIBIT NO. \_\_\_\_\_  
CASE NO. \_\_\_\_\_  
Submitted by \_\_\_\_\_  
Filing Date \_\_\_\_\_

STATE OF MINNESOTA  
ON CONSTRUCTION DIVISION  
TABLE 1.01  
2018-19  
2019-20  
2020-21

DIVISION APPROVED PLUGGING PROGRAM

B.M.N.S. Company  
Waggoner #1  
K-29-30N-12W

- (1) Clean out hole to 1659'.
- (2) Set plug at 1559'-1659'.
- (3) Perforate 5 1/2" casing at 1380'. Set a plug 1280'-1380' in and outside 5 1/2" casing. WOC at least 6 hours.
- (4) Go in hole with tubing and tag plug #2. If cement is above 1300' to to step 5. If not fill to 1280'.
- (5) Perforate 5 1/2" casing at 310'. Set a plug 50'-310' in and outside casing. WOC at least 6 hours.
- (6) Go in hole with tubing and tag plug #3. If cement is 75' or above go to step 7. If not recement to 50'.
- (7) Set a top plug with 10 sacks of cement and erect a dry hole marker.
- (8) Fill pits. Clean and level location.

All plugs will be Class A,B or C cement with or without an accelerator.