16.

## ATES SUBMIT IN TRIPLICATE. (Other instructions on reverse side)

5. LEASE DESIGNATION AND SERIAL NO.

GEOLOGICAL SURVEY	SF 04444  6. IF INDIAN, ALLOTTEE OR TRIBE NAME		
SUNDRY NOTICES AND REPORTS ON WELLS  (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  Use "APPLICATION FOR PERMIT—" for such proposals.)	7. UNIT AGREEMENT NAME		
OIL GAS WELL OTHER Water Injection Well  2. NAME OF OPERATOR	8. FARM OR LEASE NAME NE Hogback Unit		
Clinton Oil Company  3. ADDRESS OF OPERATOR  P. O. Box 2434 - Casper, Wyoming 82601  P. O. Box 2434 - Casper, Wyoming 82601	9. WELL NO. 45 10. FIELD AND POOL, OR WILDCAT		
4. LOCATION OF WELL (Report location clearly and in accordance with any state require See also space 17 below.) At surface	Horseshoe Gallup  11. SEC., T., E., M., OR BLK. AND SURVEY OR AREA		
520' FNL and 1935' FEL  14. PERMIT NO.  15. ELEVATIONS (Show whether DF, RT, GR, etc.)  5.471' CL	Sec. 14-T30N-R16W  12. COUNTY OR PARISH 13. STATE  San Juan N. Mexico		

	ale Appropriate Box To I	ndicate N	lature of <b>No</b> tice, Report, or Other	Data	
	F INTENTION TO:	-	SUBSEQUENT R	REPORT OF:	
TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL	PULL OR ALTER CASING MULTIPLE COMPLETE ABANDON* CHANGE PLANS	X	WATER SHUT-OFF  FRACTURE TREATMENT SHOOTING OR ACIDIZING  (Other)  NOTE: Report results of m Completion or Recompletion	REPAIRING WELL  ALTERING CASING ABANDONMENT*  ultiple completion on Well Report and Log form.)	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) \* proposed work. I nent to this work.)

10-3/4" - set at 110' w/75 sacks cement Casing:

5-1/2" - set at 2932' w/225 sacks cement

2722'-2758' Perf:

2820'-2851'

2856'-2863'

2875'-2884'

Baker Model "N" packer set at 2790'

Propose to squeeze 25 sacks cement down tubing below packer

Place 20 sack cement plug 2790'-2640'

Shoot off 5-1/2" casing. Pull and lay down.

Place 35 sack cement plug 50' inside and 50' above 5-1/2" casing stub

Place 60 sack cement plug 1525'-1375' (Pt. Lookout 1425-1760')

Place 40 sack cement plug 140'-60'

Place 10 sack cement plug 18'- GL

Install dry hole marker

Clean up location



18. I hereby certify that the foregoing is true and correct	TITLE District Manager	DATE Opril 30, 1974
(This space for Federal or State office use)		
APPROVED BY	TITLE	DATE