Sundry Not	tices and Reports on Wells		
		5.	Lease Number SF-078511
. Type of Well GAS	December	6.	If Indian, All. or Tribe Name
. Name of Operator	MAR - 8 1999	7.	Unit Agreement Name
BURLINGTON RESOURCES	& GAS COMPANY		
. Address & Phone No. of Opera	etor	8.	Well Name & Number Quinn #6
PO Box 4289, Farmington, N		9.	API Well No. 30-045-10600
Location of Well, Footage, Sec., T, R, M 990'FNL 990'FEL, Sec.20, T-31-N, R-8-W, NMPM			Field and Pool Blanco Mesaverde
		11.	County and State San Juan Co, NM
2. CHECK APPROPRIATE BOX TO I	NDICATE NATURE OF NOTICE, REPO	RT, OTHER	DATA
Type of Submission	Type of Action	•	
X Notice of Intent		nge of Pla	ans
		Construct	
Subsequent Report		-Routine 1	Fracturing
	Casing Repair Wat	er Shut of	ff
Final Abandonment	Altering Casing Con	version to	o Injection
	X Other -		
 Describe Proposed or Comp 	pleted Operations		
It is intended to repair attached procedur	the tubing on the subject wel	l accordi	ng to the
			, etc.
			- 7
			÷ .
// // // -	e foregoing is true and correct		
igned MAL hul	(MEL6) Title <u>Regulatory Admi</u>	nistrator	_Date 1/29/99 TLW
This space for Federal or Sta	te Office use com Leed, Petroleum Ann		MAR - 5 1999
	Cf Title	eme mbate	

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

Quinn #6 Mesaverde 990'FNL, 990' FEL

Unit A, Section 20, T-31-N, R-8-W

Latitude / Longitude: 36° 53.2525' / 107° 41.5649'

DPNO: 3227101 **Tubing Repair Procedure**

- Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental 1. regulations. Test rig anchors and build blow pit prior to moving in rig. Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS. Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
- MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow 2. well down and kill with 2% KCL water if necessary. NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
- Mesaverde, 2-3/8", 4.7# J-55 tubing is set at 5720'. Release donut, pick up additional joints of 3. tubing and tag bottom. (Record depth.) PBTD should be at +/- 5781'. TOOH with tubing. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
- If fill, TIH with 4-3/4" bit, bit sub and watermelon mill on 2-3/8" tubing and round trip to below 4. perforations, cleaning out with air/mist. NOTE: When using air/mist, minimum mist rate is 12 bph. If scale is present, contact Operations Engineer to determine methodology for removing scale from casing and perforations.
- TIH with one joint of 2-3/8" tubing with an expendable check on bottom and a seating nipple one 5. joint off bottom then ½ of the 2-3/8" production tubing. Run a broach on sandline to insure that the tubing is clear. TIH with remaining 2-3/8" tubing and then broach this tubing. Replace any bad joints. CO to PBTD with air/mist. PU above the perforations and flow the well naturally, making short trips for clean up when necessary.
- Land tubing at ±5720°. ND BOP and NU WH. Pump off expendable check. Connect to casing 6. and circulate air to assure that expendable check has pumped off. Obtain pitot gauge up the tubing. If well will not flow up the tubing, make swab run to SN. RD and MOL. Return well to production.

Recommended: M.E. hutige Operations Engineer

Approved:

Brucol Bong 1.31.99
Drilling Superintendent

Operations Engineer:

Mary Ellen Lutev

Office - (599-4052)

Home - (325-9387) Pager - (324-2671)

MEL/klg