UNITED STATES

Q21.					
DEPARTMEN	T	OF	THE	INTERI	OR
BUREAU ()F	LAN	ND MA	ANAGEME	NT

	ices and Reports on Wells		
		5.	Lease Number SF-078198
1. Type of Well		6.	-
GAS		•	Tribe Name
GAS			
		7.	Unit Agreement Na
2. Name of Operator			
BURLINGTON RESOURCES			
10000011020 OIL	& GAS COMPANY	8.	Well Name & Numbe
3. Address & Phone No. of Opera	tor	0.	Nye SRC #15
PO Box 4289, Farmington, NM		9.	
FO BOX 4289, Farmingcon, Mi	. 0/4// (303/ 320).00		30-045-20985
4. Location of Well, Footage, S	Sec., T, R, M	10.	Field and Pool
825'FNL 825'FEL, Sec.25, T-			Basin Dakota
		11.	County and State
			San Juan Co, NM
12. CHECK APPROPRIATE BOX TO IN	WOTCH NAMED OF NOTICE DE	DODT OTHER	DATA
Type of Submission	Type of Action		DAIA
X Notice of Intent		hange of Pl	ans
n notice of induit	Recompletion N	_	
Subsequent Report	Plugging Back N		
			
	Casing Repair W		
Final Abandonment	Altering Casing C	Conversion t	
Final Abandonment		Conversion t	
	Altering Casing C _X_ Other - tubing repair	Conversion t	
13. Describe Proposed or Comp	Altering Casing	Conversion t	o Injection
13. Describe Proposed or Comp	Altering Casing C _X_ Other - tubing repair pleted Operations the tubing on the subject w	Conversion t	o Injection
13. Describe Proposed or Comp	Altering Casing C _X_ Other - tubing repair pleted Operations the tubing on the subject w	Conversion t	o Injection
13. Describe Proposed or Comp	Altering Casing C _X_ Other - tubing repair pleted Operations the tubing on the subject w	Conversion t	o Injection
13. Describe Proposed or Comp	Altering Casing C_X_Other - tubing repair pleted Operations the tubing on the subject were.	Conversion t	o Injection
13. Describe Proposed or Comp	Altering Casing C _X_ Other - tubing repair pleted Operations the tubing on the subject were.	Conversion t	o Injection
13. Describe Proposed or Comp	Altering Casing C_X_Other - tubing repair pleted Operations the tubing on the subject were.	Conversion t	o Injection
13. Describe Proposed or Comp	Altering Casing C X_ Other - tubing repair pleted Operations the tubing on the subject were.	Conversion t	o Injection
13. Describe Proposed or Comp	Altering Casing C _X_ Other - tubing repair pleted Operations the tubing on the subject were.	Conversion t	o Injection
13. Describe Proposed or Comp	Altering Casing C X_ Other - tubing repair pleted Operations the tubing on the subject were.	Conversion t	o Injection
13. Describe Proposed or Comp	Altering Casing C X_ Other - tubing repair pleted Operations the tubing on the subject were.	Conversion t	o Injection
13. Describe Proposed or Comp	Altering Casing C X_ Other - tubing repair pleted Operations the tubing on the subject were.	Conversion t	o Injection
13. Describe Proposed or Comp	Altering Casing C X_ Other - tubing repair pleted Operations the tubing on the subject were.	Conversion t	o Injection
It is intended to repair attached procedur	Altering Casing C _X_ Other - tubing repair pleted Operations the tubing on the subject was a constant of the subject wa	vell accordi	o Injection
It is intended to repair attached procedur	Altering Casing C X_ Other - tubing repair pleted Operations the tubing on the subject were.	vell accordi	o Injection
It is intended to repair attached procedur	Altering Casing C _X_Other - tubing repair pleted Operations the tubing on the subject was a constant of the constant of	conversion to	pg to the
It is intended to repair attached procedur	Altering Casing C _X_ Other - tubing repair pleted Operations the tubing on the subject was a constant of the subject wa	conversion to	pg to the
It is intended to repair attached procedur	Altering Casing C _X_ Other - tubing repair pleted Operations the tubing on the subject was a constant of the subject w	conversion to	pg to the

Dakota

825' FNL & 825' FEL Unit A, Section 25, T30N, R11W

Latitude / Longitude: 36° 47.2650'/ 107° 56.1685'

DPNO: 53592

Tubing Repair Procedure

Project Summary: A wireline check indicated a crimped joint in the tubing. We propose to pull the tubing, check for fill, replace any worn or scaled tubing and install a plunger lift. The Nve SRC #15 was drilled in 1972. Tubing was last pulled during a pay add/restimulation process (12/96).

- 1. Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in **DIMS/WIMS**. Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
- MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow well 2. down and kill with 2% KCL water if necessary. NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
- The Dakota tubing is 1-1/2", 2.9#, J-55 set at 7195'. Release donut, pick up additional joints of 3. tubing and tag bottom (record depth.) PBTD should be at +/- 7219'. TOOH with tubing. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
- If fill covers any perforations then TIH with 3-7/8" bit and a watermelon mill on 1-1/2" tubing to 4. below perforations, cleaning out with air/mist. NOTE: If any torque is encountered, TOOH with 1-1/2" tubing and pick up a 2-3/8" work string. NOTE: When using air/mist, minimum mist rate is 12 bph.
- 5. PU above the perforations and flow the well naturally, making short trips for clean up when necessary. TOOH with tubing. TIH with one joint of 1-1/2" tubing with an expendable check on bottom and a seating nipple one joint off bottom. Run a broach on sandline to insure that the tubing is clear. Land tubing at approximately 7170'. ND BOP and NU WH. Pump off expendable check. Connect to casing and circulate air to assure that expendable check has pumped off. If well will not flow on it's own, make swab run to SN. RD and MOL. Return well to production.

Recommended: /

Tandaff 6/11/98 Operations Engineer

Approved:

Kevin Midkiff

Office - 599-9807

Pager - 564-1653