UNITED STATES DEPARTMENT OF THE INTERIOR

BUREAU OF LAND MANAGEMENT

		ED STATES		
	DEPARTMENT OF THE INTERIOR		SEOF.	
	BUREAU OF	LAND MANAGEMENT	182	CELVED
	Sundry Notic	es and Reports on Well	\$ 98 1.'0! 2.	
			1.07 2	Plantis 53 mb an
			070 FADI	Lease Number
L. Type of Well			6.	(1) Thi Typian, All. or
GAS		والمجاري فيدويون والراب		Tribe Name
		Annual desired of the second o	7.	Unit Agreement Name
2. Name of Operator				San Juan 32-9 Unit
BURLING	TQN	GAS COMPANDECE	A 同 DJ	
RESOURC.	ES OIL &	GAS COMPANY		•• ••
2 233 C Phone V			1999 - 8.	Well Name & Number San Juan 32-9 U#16
3. Address & Phone N PO Box 4289, Far	_		1 DMV 9	API Well No.
		(0) III GOD	10 P100	30-045-23314
4. Location of Well, 790'FSL 1780'FEL,			. D). Field and Pool Mesaverde
/90°FSL 1/80°FEL,	Sec. 6, 1-31	-N, R-9-W, MHEN	13	. County and State
				San Juan Co, NM
12 CURCE ADDODDETAT	TE BOY TO TWO	CATE NATURE OF NOTICE,	REPORT. OTH	R DATA
Type of Submission		Type of Act		
X Notice of		Abandonment	_ Change of 1	
- 1			_ New Constru	ection Fracturing
Subsequer	it Report	Plugging Back Casing Repair _	_ Non-Routing Water Shut	
Final Aba	andonment	Altering Casing	_	to Injection
—		_X_ Other -		
13 Peggmibe Prope	aged or Comple	eted Operations		
13. Describe Propo	osed or Comple	eted Operations		
		-		dian to the
It is intended	d to repair t	he tubing on the subjec	t well accor	ding to the
It is intended		he tubing on the subjec	t well accor	ding to the
It is intended	d to repair t	he tubing on the subjec	t well accor	ding to the
It is intended	d to repair t	he tubing on the subjec	t well accor	ding to the
It is intended	d to repair t	he tubing on the subjec	t well accor	ding to the
It is intended	d to repair t	he tubing on the subjec	t well accor	ding to the
It is intended	d to repair t	he tubing on the subjec	t well accor	ding to the
It is intended	d to repair t	he tubing on the subjec	t well accor	ding to the
It is intended	d to repair t	he tubing on the subjec	t well accor	ding to the
It is intended	d to repair t	he tubing on the subjec	t well accor	ding to the
It is intended attach	d to repair the led procedure.	he tubing on the subjec		ding to the
It is intended attach	d to repair the led procedure.	he tubing on the subjec		ding to the
It is intended attach	d to repair the	he tubing on the subjec	correct.	
It is intended attach	ity that the	foregoing is true and o	correct. Administrat	<u>or</u> Date 11/18/98

San Juan 32-9 Unit #16A

Mesaverde 790'FSL, 1780' FEL

Unit O, Section 8, T-31-N, R-9-W

Latitude / Longitude: 36° 54.4455' / 107° 48.0084'

DPNO: 69853

Tubing Repair Procedure

- 1. Hold safety meeting. Comply with all NMCCD, BLM and Burlington safety and environmental regulations. Test rig anchors and bailed blow pit palor to moving in rig. Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping an cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If y rbal approval is obtained, document approval in DIMS/WIMS. Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
- MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow 2. well down and kill with 2% KCL water if necessary. NU BOP with stripping head. Test and second operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace install as necessary.
- 3. Mesaverde, 2-3 8", 4.7# J-55 tubing is set at 6.30". Release donut, pick up additional joints of tubing and tag bottom. (Record depth.) PBTD should be at ±/- 6173'. TOOH with tubing. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
- If fill, TIH with 3-7/8" bit, bit sub and watermelon mill on 2-3/8" tubing and round trip to below 4. perforations, cleaning out with air mist. NOTE: When using air/mist, minimum mist rate is 12 bph. If scale is present, contact Operations Engineer to determine methodology for removing scale from casing and perforations.
- TIH with one joint of 2-3/8" tubing with an expendable check on bottom and a seating nipple one 5. joint off bottom then ½ of the 2-3.8" production tubing. Run a broach on sandline to insure that the tubing is clear. TIH with remaining 2-3/8" tubing and then broach this tubing. Replace any bad joints. CO to PBTD with air mist. PU above the perforations and flow the weil naturally, making short trips for clean up when necessary.
- 6. Land tubing at ±6090'. ND BOP and NU WH. Pump off expendable check. Connect to easing and circulate air to assure that expendable check has pumped off. Obtain pitot gauge up the tubing. If well will not flow up the tubing, make swab run to SN, RD and MOL. Return well to production.

Recommended: M. E. A. Train
Operations Engineer

ed: Brilling Superintendent

Operations Engineer:

Mary Ellen Lutev

Office - (599-4052) Home - (325-9387)

Pager - (324-2671)