

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

RECEIVED  
BLM

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well  
☐ Oil Well ☐ Gas Well ☒ Other Dry hole

2. Name of Operator  
Jack J. Grynberg

3. Address and Telephone No.  
5000 S. Quebec Street, Suite 500, Denver, CO 80237 (303)850-7490

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)  
1060 FNL, 805 FWL Sec. 26, T32N, R5W

5. Lease Designation and Serial No.  
NM 29342

6. If Indian, Allotment or Tribe Name  
N/A

7. If Unit or CA, Agreement Designation  
Carracas Canyon

8. Well Name and No. ~~UAF 1-26~~  
Federal 1-26

9. API Well No.  
30-039-07991

10. Field and Pool, or Exploratory Area  
Wildcat

11. County or Parish, State  
Rio Arriba, N.M.

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other

RECEIVED  
APR 18 1994  
OIL CON. DIV.  
DIST. 3

- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion or Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

We plan to plug this well as follows:

1. Cut off 2 3/8 tubing at top of packer  $\pm$  6160.
2. Set cement retainer on wire line at 6100. Squeeze 10 sx cement below retainer-- pull out of retainer and spot 15 sx on top of retainer.
3. Perforate 4 holes 50' below top of Picture Cliffs at 3880' and 50 above base of Ojo Alamo at 3210. Set cement retainer on wire line at  $\pm$  3250. Circulate 4 1/2 x 8 3/4 annulus with lite cement. Spot 50 sx plug from retainer to 3070; (50' above top of Ojo Alamo).

Note: Previous re-entry in May, 1990 squeezed holes in 4 1/2 casing from 2861 to 3080, therefore the top of the Ojo Alamo should be covered with cement behind the 4 1/2 casing.

4. Circulate cement plug from 368' to surface inside 4 1/2 casing.
  5. Cut off casing, install dry hole marker and rehabilitate location.
- Note: This work will be done during the priod when the Forest Service opens up the roads for summer season, from May 1-November 1. Exact timing will depend upon the availability of a service rig.

14. I hereby certify that the foregoing is true and correct

Signed Ken R. McKinney *KRM* Engineer

Date 4/7/94

(This space for Federal or State office use)

Approved by \_\_\_\_\_  
Conditions of approval, if any:

Title \_\_\_\_\_

Date \_\_\_\_\_

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

\*See Instruction on Reverse Side

NMOC

APPROVED