

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-	7. Unit Agreement Name San Juan 32-5 Unit
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name San Juan 32-5 Unit
3. Address of Operator Box 990, Farmington, New Mexico	9. Well No. 5
4. Location of Well UNIT LETTER M , 990 FEET FROM THE South LINE AND 790 FEET FROM THE West LINE, SECTION 24 TOWNSHIP 32-N RANGE 6-W NMPM.	10. Field and Pool, or Wildcat Basin Dakota
15. Elevation (Show whether DF, RT, GR, etc.) 6336' GL	12. County Rio Arriba

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to mechanical condition it is planned to plug and abandon this well as follows:


Spot a 50 sack cement plug on tubing stub at 5580'.

Perf 4 squeeze holes (3300-3301'), spot a 50 sack cement plug over perfs and squeeze.

Spot a 50 sack cement plug over parted casing at 1383' and squeeze.

Pump a 75 sack cement plug down bradenhead.

Spot a 10 sack cement plug in surface with a 4' x 4" Plug and Abandonment marker.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Original Signed By: L. O. Van Ryan TITLE Petroleum Engineer DATE August 12, 1969

APPROVED BY Emmye Lewis TITLE Sup Dist III DATE 8-14-69

CONDITIONS OF APPROVAL, IF ANY: