

Spur 0.11 c

Quinlan Ranch #1

H-23-22N-02E

2000' N.L. + 100' F.W.L.

Downhole conditions and equipment

8 5/8" casing at 513' cemented with 448 cu. ft of cement *08*

5 1/2" casing at 3865' with 1019 cu. ft of cement

Cement top 740'

Division Approved Plugging Program

1. Go in hole with tubing to TD and set a cement plug 3865'-3600' inside casing.
2. Pull out of hole to 3320' and set a cement plug 3320'-3188' inside casing.
3. Pull out of hole to 2830 and set a cement plug 2830'-2429' inside casing.
4. Pull out of hole with tubing and find 5 1/2" casing free point. Shoot off casing at free point and pull same. Spot a 150' cement plug at casing stub.
5. Set a top plug 130' to surface.
6. Set a dry hole marker, fill pits, clean and level location.

All plugs will be with neat cement with or without an accelerator.