

Spur

Texas Rose Petroleum Inc.
Quinlan Ranch #1 B-29-32N-3E - old survey
Projected NMAPM H-23-32N-2E 4000FNL 100FWL
Survey

Downhole conditions and equipment
8 5/8" casing at 513' cemented with 448 cu. ft of cement
5 1/2" casing at 3865' with 1019 cu. ft of cement
Cement top 740' *OS*

Division Approved Plugging Program

1. Go in hole with tubing to TD and set a cement plug 3865'-3600' inside casing.
2. Pull out of hole to 3320' and set a cement plug 3320'-3188' inside casing.
3. Pull out of hole to 2830 and set a cement plug 2830'-2429' inside casing.
4. Pull out of hole with tubing and find 5 1/2" casing free point. Shoot off casing at free point and pull same. Spot a 150' cement plug at casing stub.
5. Set a top plug 130' to surface.
6. Set a dry hole marker, fill pits, clean and level location.

All plugs will be with neat cement with or without an accelerator.

