

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN THE MANNER  
(Other instructions on reverse side)Form approved.  
Budget Bureau No. 42-R142A.5. LEASE DESIGNATION AND SERIAL NO.  
**Ute Mtn. Tribal Contract**  
**14-20-604-82**

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

**Ute Mtn. Tribe of Indians**

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

**Ute-Indian**

9. WELL NO.

**1-20**

10. FIELD AND POOL, OR WILDCAT

**Verde Gallup**11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA**20-31N-14W N.M. PM**

12. COUNTY OR PARISH

**San Juan**

13. STATE

**New Mexico**

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

**Empire State Oil Company**

3. ADDRESS OF OPERATOR

**Box 871 Thermopolls, Wyoming**4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface**660' FSL & 660' FWL Sec. 20-T31N-R14W**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

**5614 GR**

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON\* ☐CHANGE PLANS ☐

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT\* ☒(Note: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

The above well was plugged and abandoned as follows:

1. Set 20 sack cement plug across Gallup formation. Top of cement plug at 3230' in 5-1/2" casing.
2. Filled casing with heavy mud.
3. Shot 5-1/2" casing off at lowest free point - 1500' and pulled casing from hole.
4. Set 22 sack cement plug from 1450'-1550'.
5. Set 15 sack cement plug in bottom surface casing.
6. Set 10 sack cement plug in top surface casing.
7. Erected regulation dry hole marker and cleaned location.
8. Well plugged and abandoned 2-5-67.

18. I hereby certify that the foregoing is true and correct

SIGNED

**Thomas E. Fenno**

(This space for Federal or State office use)

TITLE

**Engineer**

DATE

**2-22-67**

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED

MAR 28 1967

E. A. SCHMIDT  
ACTING DISTRICT ENGINEER

\*See Instructions on Reverse Side

100-1000

