

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

14-20-604-83

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

Ute Mountain

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Ute Mountain

9. WELL NO.

#7

10. FIELD AND POOL, OR WILDCAT

Verde Gallup

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

21-31N-R14W

12. COUNTY OR PARISH 13. STATE

San Juan

NM

1. OIL ☒ GAS ☐
WELL WELL OTHER

2. NAME OF OPERATOR

Benson-Montin-Greer Drilling Corp.

3. ADDRESS OF OPERATOR

221 Petroleum Center Bldg. Farmington, NM

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1980' South of 1980' West of Sec. 21

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

5626 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☐

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Operator requests approval to extend temporary abandonment status on this well pending outcome of possible water flood leak off into producing zones.

18. I hereby certify that the foregoing is true and correct

SIGNED

Virgil L. Steads

TITLE Vice-President

DATE 6-14-79

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO. 14-20-604-83
2. NAME OF OPERATOR Benson-Montin-Greer Drilling Corp.		6. IF INDIAN, ALLOTTEE OR TRIBE NAME Ute Mountain Tribal
3. ADDRESS OF OPERATOR 221 Petroleum Center Building, Farmington, NM 87401		7. UNIT AGREEMENT NAME -
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' FSL, 1980' FWL, Sec. 21, T-31N, R-14W		8. FARM OR LEASE NAME Ute Mountain Tribal
14. PERMIT NO.		9. WELL NO. #7
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 5626' GR		10. FIELD AND POOL, OR WILDCAT Verde Gallup
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec 21, T-31N, R-14W
		12. COUNTY OR PARISH San Juan
		13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input checked="" type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	(Other) <input type="checkbox"/>

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Operator requests approval to plug and abandon.

See attachment for plugging and abandoning procedure.

RECEIVED
NOV 29 1983
OIL CON. DIV.
DIST. 3RECEIVED
Bureau of Land Management

NOV 14 1983

Durango, Colorado

18. I hereby certify that the foregoing is true and correct.

SIGNED <i>David J. Miller</i>	TITLE Vice-President	DATE November 10, 1983
(This space for Federal or State office use)		
APPROVED BY David J. Miller	TITLE Area Manager	DATE NOV 21 1983
CONDITIONS OF APPROVAL, IF ANY:		

*See Instructions on Reverse Side

14-20-604-83
Well No. 7 NESW 21-39N-14W

LS

5635 df 5623 pl

8 7/8 @ 115 w/ 100 AX

mf 524

Pl. 20 1253

Rm 1601

Top of B 1500

Gallup 2616

5 1/2 @ 2825 w/ 230 AX

2. Gallup 2875

~~4~~ 4 slotted liner 2820-2940
~~2869-2953~~

TD 2953 2945 sidetracked hole

9.5 #/gal or heavier fresh gel mud between plugs

1. Spot a 200' cement plug from 2945' TD to 2745'.
2. Spot a 100' cement plug from 1650' to 1550' inside 5 1/2" casing across top of Mancos.
3. Cut and pull 5 1/2" casing. Calculated top of cement is approximately 1400'-1500'.
4. Spot a 100' cement plug, 50' inside the casing and 50' on top of the cut off.
5. Spot a 185' cement plug from 185' to surface.

- c. Cut off $8\frac{5}{8}$ " casing below ground level. Weld a $\frac{1}{4}$ " steel plate across $8\frac{5}{8}$ " casing. Erect P & A marker. Clean and restore surface. Restoration and seeding requirements will be forthcoming.

If $5\frac{1}{2}$ " casing cannot be cut and pulled

3. Perforate $5\frac{1}{2}$ " casing at ~~100'~~ 150'. Establish circulation to surface through $5\frac{1}{2}$ " by $8\frac{5}{8}$ " annulus. Circulate cement to surface.
4. Spot a 50' cement plug from 50' to surface inside $5\frac{1}{2}$ " casing
5. Cut off ~~5"~~ casing below ground level. Weld a $\frac{1}{4}$ " steel plate across $8\frac{5}{8}$ " casing. Erect P & A marker. Clean and restore surface. Restoration and seeding requirements will be forthcoming

CAB/10-31-83