

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT - " for such proposals

5. Lease Designation and Serial No.

SF-078051

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Neil LS #5

9. API Well No.

3004510653

10. Field and Pool, or Exploratory Area

Blanco Mesaverde

11. County or Parish, State

San Juan New Mexico

1. Type of Well
☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator Attention:
Amoco Production Company Gail M. Jefferson, Rm 1942

3. Address and Telephone No.
P.O. Box 800, Denver, Colorado 80201 (303) 830-6157

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
880' FSL 1600FWL Sec. 14 T 31N R 11W

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☒ Other Plug and Abandon
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Amoco Production Company requests permission to plug and abandon the above referenced well per the attached procedures.

If you need any additional information please contact me at the telephone number listed above.

RECEIVED
MAR - 5 1995

OIL CON. DIV.
DIST. 3

SEE ATTACHED FOR
CONDITIONS OF APPROVAL

14. I hereby certify that the foregoing is true and correct

Signed Gail M. Jefferson Title Business Assistant Date 02-28-1995

(This space for Federal or State office use)

Approved by _____ Title _____
Conditions of approval, if any:

APPROVED

MAR 03 1995

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious, or fraudulent statements or representations as to any matter within its jurisdiction.

* See Instructions on Reverse Side


NMOCD

s/s Enol Becher

PXA Procedures
Neil LS #5

1. Check location for anchors. Install if necessary. Test anchors.
2. MIRUSU. Test casing integrity to 500#. POOH with 2 3/8" tbg. Run CBL from 1240' to 2680' to determine TOC.
3. Depending where TOC is besure the PC is isolated from the Fruitland Coal and Fruitland Coal is isolated from the Ojo Alamo, by perfing and squeezing. (estimated 90.18 cuft cement)
4. Pull up hole and spot 100' plugs across the PC, Fruitland, Ojo Alamo and 223 to surface with 126.633 cuft estimated cement.
5. NDBOPE. Cut off casing and wellhead. Install PXA marker according to BLM or State requirements.
6. Turn over to John Schwartz for reclamation.
7. Rehabilitate location according to BLM or State requirements.

NEIL LS 005 1648
Location - 14N- 31N-11W
SINGLE MV
Orig. Completion - 8/53
LAST FILE UPDATE - 9/91 BY CSW



FILENAME:
04510653

04510653

UNITED STATES DEPARTMENT OF THE INTERIOR

**BUREAU OF LAND MANAGEMENT
FARMINGTON DISTRICT OFFICE**

1235 La Plata Highway
Farmington, New Mexico 87401

Attachment to Notice of

Re: Permanent Abandonment

Intention to Abandon

Well: 5 Neil LS

CONDITIONS OF APPROVAL

1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal and Indian Leases."

2. **Mike Flaniken** with the Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 599-8907.

3. The following modifications to your plugging program are to be made (when applicable):

1.) At a minimum, spot the following cement plugs:

A.) Place a cement plug from 2557' to 2457' inside the casing plus 50 linear feet excess cement. (top of Pictured Cliffs @ 2507')

B.) Place a cement plug from 2150' to 1970' inside the casing plus 50 linear feet excess cement. (top of Fruitland Coal @ 2100' -- bottom of cement from CBL @ 2020')

C.) Place a cement plug from 979' to 879' inside the casing plus 50 linear feet excess cement. (top of Kirtland or bottom of Nacimiento @ 929')

D.) Place a cement plug from 223' to the surface inside the casing.
(surface shoe @ 173')