

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Sundry Notices and Reports on Wells

1. Type of Well
GAS

2. Name of Operator
BURLINGTON RESOURCES OIL & GAS COMPANY

3. Address & Phone No. of Operator
PO Box 4289, Farmington, NM 87499 (505) 326-9700

4. Location of Well, Footage, Sec., T, R, M
950' FNL 890' FEL, Sec.33, T-32-N, R-9-W, NMPM

5. Lease Number
SF-079048

6. If Indian, All. or Tribe Name

7. Unit Agreement Name
San Juan 32-9 Unit

8. Well Name & Number
San Juan 32-9 U#71

9. API Well No.
30-045-11195

10. Field and Pool
Blanco Mesaverde

11. County and State
San Juan Co, NM

RECEIVED
MAR 15 1999
OIL CON. DIV.
DPL 3

12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTHER DATA

Type of Submission	Type of Action
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Abandonment
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion
<input type="checkbox"/> Final Abandonment	<input type="checkbox"/> Plugging Back
	<input type="checkbox"/> Casing Repair
	<input type="checkbox"/> Altering Casing
	<input checked="" type="checkbox"/> Other -
	<input type="checkbox"/> Change of Plans
	<input type="checkbox"/> New Construction
	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Water Shut off
	<input type="checkbox"/> Conversion to Injection

13. Describe Proposed or Completed Operations

It is intended to repair the tubing on the subject well according to the attached procedure.

14. I hereby certify that the foregoing is true and correct.

Signed Shawn Smith (MEL) Title Regulatory Administrator Date 2/25/99
TLW

(This space for Federal or State Office use)
APPROVED BY Chip Hansen Title Acting Land Lead Date 3/11/99
CONDITION OF APPROVAL, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

San Juan 32-9 Unit #71
Mesaverde
950'FNL, 890' FEL
Unit A, Section 33, T-32-N, R-9-W
Latitude / Longitude: 36° 56.7471' / 107° 46.7157'
DPNO: 6996601
Tubing Repair Procedure

1. Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. **Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS.** Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
2. MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow well down and kill with 2% KCL water if necessary. ND wellhead and NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
3. Mesaverde, 1-1/4", 2.4# J-55 tubing is set at 5955'. Release donut, pick up additional joints of tubing and tag bottom. (Record depth.) PBDT should be at +/- 5995'. TOOH and stand back tubing. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
4. If fill is encountered, TIH with 4-3/4" bit, bit sub and watermelon mill on 2-3/8" workstring and round trip to below perforations, cleaning out with air/mist. **NOTE: When using air/mist, minimum mist rate is 12 bph.** If scale is present, contact Operations Engineer to determine methodology for removing scale from casing and perforations. TOOH laying down workstring.
5. TIH with one joint of 1-1/4" tubing with an expendable check on bottom and a seating nipple one joint off bottom then 1/2 of the 1-1/4" production tubing. Run a broach on sandline to insure that the tubing is clear. TIH with remaining 1-1/4" tubing and then broach this tubing. Replace any bad joints. CO to PBDT with air/mist. PU above the perforations and flow the well naturally, making short trips for clean up when necessary.
6. Land tubing at ±5925'. ND BOP and NU WH. Pump off expendable check. Connect to casing and circulate air to assure that expendable check has pumped off. Obtain pitot gauge up the tubing. If well will not flow up the tubing, make swab run to SN. RD and MOL. Return well to production.

Recommended: M.E. Lutey
Operations Engineer

Approved: Bruce W. Boyl 2/1/99
Drilling Superintendent

Operations Engineer: Mary Ellen Lutey
Office - (599-4052)
Home - (325-9387)
Pager - (324-2671)

MEL/klg