

submitted in lieu of Form 3160-5

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

Sundry Notices and Reports on Wells

RECEIVED  
BLM

98 NOV 24 PM 2:13

070 FARMINGTON NM  
5. Lease Number SF-078507

1. Type of Well  
GAS

6. Indian, All. or  
Tribe Name

2. Name of Operator

**BURLINGTON  
RESOURCES**

OIL & GAS COMPANY

Unit Agreement Name  
San Juan 32-9 Unit

3. Address & Phone No. of Operator

PO Box 4289, Farmington, NM 87499 (505) 326-9700

4. Location of Well, Footage, Sec., T, R, M

990' FSL 1650' FWL, Sec.25, T-32-N, R-10-W, NMPM

8. Well Name & Number

San Juan 32-9 U#9

9. API Well No.

30-045-11219

10. Field and Pool

Mesaverde

11. County and State

San Juan Co, NM

12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTHER DATA

Type of Submission

Type of Action

☒ Notice of Intent

☐ Abandonment

☐ Change of Plans

☐ Subsequent Report

☐ Recompletion

☐ New Construction

☐ Final Abandonment

☐ Plugging Back

☐ Non-Routine Fracturing

☐ Casing Repair

☐ Water Shut off

☐ Altering Casing

☐ Conversion to Injection

☒ Other -

13. Describe Proposed or Completed Operations

It is intended to repair the tubing on the subject well according to the attached procedure.

14. I hereby certify that the foregoing is true and correct.

Signed [Signature] (MEL4) Title Regulatory Administrator Date 11/18/98

TLW

(This space for Federal or State Office use)

APPROVED BY /s/ Duane W. Spencer Title \_\_\_\_\_

Date

DEC - 1 1998

CONDITION OF APPROVAL, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

NMOCO

**San Juan 32-9 Unit #9**  
**Mesaverde**  
**990' FSL, 1650' FWL**  
**Unit N, Section 25, T-32-N, R-10-W**  
**Latitude / Longitude: 36° 57.076' / 107° 50.2597'**  
**DPNO: 69846**  
**Tubing Repair Procedure**

1. Note: This is an openhole completion. A 24 hour rig is recommended. Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. Notify BROG Regulatory (Peggy Bradfield, 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS. Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
2. MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow well down and kill with 2% KCL water if necessary. ND wellhead and NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace install as necessary.
3. Mesaverde, 2-3/8" 4.7#, J-55 tubing is set at 5616'. Release donut, pick up additional joints of tubing and tag bottom. (Record depth.) PBTD should be at +/- 5620'. TOOH with tubing. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
4. TIH with 4-3/4" bit and bit sub on 2-3/8" tubing and round trip to PBTD, cleaning out with air/mist. **NOTE: When using air/mist, minimum mist rate is 12 bph.** If scale is present, contact Operations Engineer to determine methodology for removing scale.
5. TIH with one joint of 2-3/8" tubing with an expendable check on bottom and a seating nipple one joint off bottom then 1/2 of the 2-3/8" production tubing. Run a broach on sandline to insure that the tubing is clean. TIH with remaining 2-3/8" tubing and then broach this tubing. Replace any bad joints. CO to PBTD with air/mist. PU above the open hole and flow the well naturally, making short trips for clean up when necessary.
6. Land tubing at ±5600'. ND BOP and NU WH. Pump off expendable check. Connect to casing and circulate air to assure that expendable check has pumped off. Obtain pitot gauge up the tubing. If well will not flow up the tubing, make swab run to SN. RD and MOL. Return well to production.

Recommended: M.E. Lutey  
Operations Engineer

Approved: Bruce L. Boyer  
Drilling Superintendent

Operations Engineer: Mary Ellen Lutey  
Office - (599-4052)  
Home - (325-9387)  
Pager - (324-2671)

MEL/kg