

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-	7. Unit Agreement Name Allison Unit
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name Allison Unit
3. Address of Operator Box 990, Farmington, New Mexico - 87401	9. Well No. 4
4. Location of Well UNIT LETTER M , 990 FEET FROM THE South LINE AND 990 FEET FROM THE West LINE, SECTION 11 TOWNSHIP 32N RANGE 7W NMPM.	10. Field and Pool, or Wildcat Blanco Mesa Verde
15. Elevation (Show whether DF, RT, GR, etc.) 6658' GL	12. County San Juan

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>

PLUG AND ABANDON	<input checked="" type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>
CASING TEST AND CEMENT JOBS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

ALTERING CASING	<input type="checkbox"/>
PLUG AND ABANDONMENT	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-production it is planned to plug and abandon this well as follows:

Run perforating gun and shoot 4 holes in the casing opposite the Pictured Cliffs formation (3323') and 4 holes opposite the Kirtland at 2460'. (No tubing in this well).

Run work string, spot a 100 sacks of cement on bottom, come up the hole and spot a 25 sack plug at 3323', spot a third 25 sack plug at 2460', pull work string.

Determine freepoint of 7", 23#, J-55 casing by the stretch method, shoot casing off above the freepoint, spot a 50 sack plug on the casing stub by displacing cement down the freed casing, pull casing.

Spot a 25 sack plug at the base of the surface casing.

Place a 10 sack plug at the surface and install a dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Original Signed F. H. WOOD,

TITLE Petroleum Engineer

DATE 10-22-69

APPROVED BY

Emmy Clouds

TITLE

Sup. Dist. III

DATE

10-23-69

CONDITIONS OF APPROVAL, IF ANY:

