40

GRAND JUNCTION, CO

UNITED STATES

SUNDRY NOTICES AND REPORTS ON WEL

It not use this form for proposals to this prito deepen on thug back to a tifferent tashfold to deepen on thug back to a tifferent tashfold to deepen on the proposals.

2. NAME OF OPERATOR ARICO DELL and Pas Co., a

12.

AT SUPFACE: 1900' FNL & 2050' FWL, Sec. 27

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE.

9.0. Bom 5540, Denver, Colo.

DEPARTMENT OF THE INTERIOR 1 2 1983 GEOLOGICAL SURVEY

Atlantic Richfiels Company

1750

REPORT LOCATION CLEARLY. See space 17

14-20-604-1951

6. IF INDIAN, ALLOTTEE OR TRIBE NAME Ute Mtn.

## 7. UNIT AGREEMENT NAME Horseshoe Gallup Unit

3. FARM OR LEASE NAME Horseshoe Gallup Unit

9. WELL NO

156 10. FIELD OR WILDOAT NAME Horseshoe Gallup

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 27-31N-16W

12. COUNTY OR PARISH 13. STATE New Mexico San Juan

14. API NO.

None Assigned 15. ELEVATIONS (SHOW DF, KDB, AND WD) 5767' GR

(NOTE: Report results of multiple completion or zone SUM change on Form 9-330.)

SUBSEQUENT REPORT OFF

TEST WATER SHUT-OFF =FRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL PULL OR ALTER CASING MULTIPLE COMPLETE

REQUEST FOR APPROVAL TO:

3. ADDRESS OF OPERATOR

4. LOCATION OF WELL

AT TOTAL DEPTH:

below Unit F,

AT TOP PROD. INTERVALL

REPORT, OR OTHER DATA

CHANGE ZONES ABANDON\* (other)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates. including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

\$11-1-82

This notice supercedes our Sundry Notices dated August 31, 1982 on the subject well.

ARCO now proposes to plug and abandon this well, as per the attached revised P & A Procedure.

(This is in compliance with the requirements as set forth in a memorandum dated September 30, 1981, and a subsequent letter of April 26, 1982 , both from the State of New Mexico, Energy and Minerals Department, Oil Conservation Division (copies attached to our August 31, 1982 Sundry Notice).

Subsurface Safety Valve: Manu. and Type	Set @ Ft.
18. I hereby certify that the foregoing is true and correct  SIGNED Stephen Kose TITLE Dist.Prod.Supt.oa	December 20, 1982
APPROVED BY Original Signed - Scott L. Ellis CONDITIONS OF APPROVAL IF ANY:  OTHER SPACE for Federal or State office use)  TITLE  District Supervisor  [ ]	JAN 1 3 1983
CONDITIONS OF APPROVAL IF ANY: District Supervisor	JAH 1 7 1983

\*See Instructions on Reverse Side

OIL CON. DIV.

## HORSESHOE GALLUP UNIT INJECTION WELLS PLUGGING AND ABANDONMENT PROCEDURE (REVISED)

- 1. MIRU.
- 2. Release packer and pull tubing and packer out of hole.
- 3. RIH with tbg open-ended to below the bottom perforation and pump sufficient cement to cover top perforation by 50' inside the casing.
- 4. POH w/tbg. GIH w/wireline and shoot enough holes in production string opposite 150' above top perforation to allow cement squeezing of zone. (This may be necessary since the original cement job may not have covered the Gallup formation by 50'). Squeeze sufficient cement to place a 100' plug outside the casing. Also, leave a 100' plug inside the casing. If unable to squeeze plug outside the casing, leave a 100' plug inside the casing.
- 5. POH w/tbg. GIH w/wireline and shoot enough holes in production casing opposite a point 50' below the surface casing shoe to allow squeezing cement.
- 6. RIH w/tbg open-ended and perform a braden-head squeeze of the perforations. Use sufficient cement for a 100' column behind the casing and a 100' plug inside the casing.
- 7. POH, cut casing one foot below ground level, place a 30' cement plug inside casing, weld on a blind flange, weld a dry hole marker on the blind flange, fill hole and move off.
- 8. Rehabilitate location and access road using stipulations supplied by the surface management agency.

NOTE: BOP's will not be needed in most cases because expected reservoir pressure of the Gallup in the area of abandonment is very low. (Estimated at less than 250 - 300 psi bottom-hole.) If pressure does exist on any of the subject wells, bleed it off, install BOP's if needed, and commence with above procedure.



1000

## TABLE I

Horashoe Sallup Unit Federal Lease No. 14-08-001-8200 San Juan County, New Mexico.

## list of Wells

		*5-	<del>2</del> _		
	ile -	-29	خ		
3.	No.	103	â		
4.	No.	105	A		
5.	No.	113	A		
<del>) 5.</del>	<del>-110</del>	-26-	<u></u>		
	No.				
з.	No.	132	C		
9.	No.	135	C		
10.	No.	137	C		
11.	No.	139	C		
12.	No.	141	C		
13.	No.	143	D		
14.	No.	145	D		
15.	No.	148	D		
16.	No.	150	D		
17.	No.	152	D		
18.	No.	154	D		
19.	No.	156	D		
-90_		<u>-160</u> .			

21.	No.	215	)	
	No.	162	-6-	
23.				
24	No.	169	<del>- 3-</del>	
25.	No.	171	D	
26.	No.	173	D	
27.	No.	175	D	
<del>- 22</del>	No.	-130-	-	
29.	No.	132	D	
30.	No.	184	D	
31.	No.	186	٥	
32.	No.	192	<del>-0</del>	
33.	No.	194	D	
34.	No.	196	D	
<del>-35.</del> -	No.	201	-	
36.	No.	203	D	
37.	No.	205	D	
38.	No.	207	D	
39.	No.	213	Q	
40.	No.	217	D	

	; • •	No.	223	2
	42.	No.	225	<del>-</del> بر
Sat-	43.	Xo.	227	2
	44.	No.	229	D
	45.	No.	238	Ç
(अंद्रास्	46.	Nc.	240	Δ
	47.	No.	248	$\supset$
/	48.	No.	250	
	49.	No.	259	D
•	50.	No.	261	C
	51.	No.	263	<u>_</u>
	52.	No.	269	C
	53.	No.	274	C
	54.	No.		C
	5 <b>5.</b>	No.	73	Ą
	56.	NO.	199	-
	<del>-57.</del>	No:	211	

LIST. 3