

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

Use "APPLICATION FOR PERMIT -" for such proposals

5. Lease Designation and Serial No.

SF - 078097

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Heaton LS

22

9. API Well No.

30-045-20315

10. Field and Pool, or Exploratory Area

Aztec (Pictured Cliffs)

11. County or Parish, State

SAN JUAN

NEW MEXICO

1. Type of Well
☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

AMOCO PRODUCTION COMPANY

3. Address and Telephone No.

P.O. BOX 3092 HOUSTON, TX 77253

281-366-4491

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1575' FNL

900' FWL

Sec. 28 T 31N R 11W

UNIT E

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

TYPE OF ACTION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☒ Other BLM LTR 9/10/1999

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Amoco Production Company request approval to plug and abandon the subject well as follows:

1. Notify regulatory agencies (BLM, NMOCD, FIMO) 24 hours in advance of plugging activity. Contact BLM and indicate well is allotted (FIMO regulations effective April 1, 1997).
2. Check location for anchors. Install if necessary. Test anchors.
3. Rigless operation. Blow down well.
4. Bullhead Class B neat cement down casing to abandon PC. Leave top of cement at 1,400'. Wait on cement 3 hours. Perforate squeeze holes at 1,400'. Pump down casing and circulate cement to surface. Use 65:35 POZ and tail in with 100 sacks Class B neat cement leaving casing full of cement.
5. Cut off casing and wellhead. Install PXA marker according to BLM or State requirements.
6. Contact FMC and ship surface equipment to yard or other location per instructions.
7. Provide workorder to Buddy Shaw for reclamation.
8. Rehabilitate location according to BLM or State requirements.

14. I hereby certify that the foregoing is true and correct

Signed

Title

Sr. Business Analyst

Date

02-10-2000

(This space for Federal or State office use)

/s/ Charlie Beecham

Approved by

Title

Date

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious, or fraudulent statements or representations as to any matter within its jurisdiction.

* See Instructions on Reverse Side

RECEIVED