

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT  
Sundry Notices and Reports on Wells

1. Type of Well  
Oil

2. Name of Operator

Texas Pacific Oil & Gas Co., C/O Joseph E. Seagrams & Sons, Inc.

3. Address & Phone No. of Operator

800 3<sup>rd</sup> Ave., New York City, NY 10022-7699

4. Location of Well, Footage, Sec., T, R, M

2300' FSL and 712' FWL Sec. 27, T-32-N, R-17-W, NMPM

L

5. Lease Number  
14-20-603-5012

6. If Indian, All. or  
Tribe Name  
Navajo

7. Unit Agreement Name  
N/A

8. Well Name & Number  
Navajo #16-~~2~~

9. API Well No.  
30-045-2220300

10. Field and Pool  
Many Rocks

11. County & State  
San Juan County, NM

12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTHER DATA

Type of Submission

Type of Action

☒ Notice of Intent

☒ Abandonment

☐ Change of Plans

☐ Subsequent Report

☐ Recompletion

☐ New Construction

☐ Final Abandonment

☐ Plugging Back

☐ Non-Routine Fracturing

☐ Casing Repair

☐ Water Shut off

☐ Altering Casing

☐ Conversion to Injection

☐ Other -

13. Describe Proposed or Completed Operations

Texas Pacific Oil and Gas Co., proposes to Plug and Abandon this well per the attached procedure and diagram.

RECEIVED  
MAR - 3 1997

OIL CON. DIV.  
DIST. 3

UFO to Bureau of Land  
27 FEB 26 PM 0:17

14. I hereby certify that the foregoing is true and correct.

Signed William F. Clark  
William F. Clark, A-Plus Well Service

Title Contractor

Date 2/24/97

(This space for Federal or State Office use)

APPROVED BY \_\_\_\_\_ Title \_\_\_\_\_ Date FEB 27 1997

CONDITION OF APPROVAL, if any:

NM/COD

# Navajo #16-27

## Proposed P&A

Many Rocks Gallup

2300'S, 712'W Sec 27, T-32-N, R-17-W, San Juan County, NM


Today's Date: 2/21/97

Spud: 12/27/76

Completed: 2/10/77

Point Lookout @ Surface

Gallup @ 991'



### Well History:

7" Surface Casing set at 30' cemented to surface

4-1/2" Casing cemented with 25 sxs.

Gallup zone perforated 1317' - 1329'

Rods, American D-25 Pump Jack with no motor.  
2-3/8" tubing @ 1339'

### Proposed Plugging Procedure:

1. Test tubing. Pull rods. Tag bottom. Plug #1 from 1340' to 941' with 46 sxs Class B cement. POH with tubing.
2. WOC and then RIH and tag cement. Pressure test casing to 300#. POH with tubing.
3. Perforate 2 squeeze holes at 80'. Establish circulation out bradenhead. Mix and pump 14 sxs Class B cement from 80' to surface, circulate good cement out bradenhead.
4. WOC then cut off wellhead and install P&A marker.