

submitted in lieu of Form 3160-5

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Sundry Notices and Reports on Wells

1. Type of Well GAS	5. Lease Number SF-078146
2. Name of Operator Southland Royalty	6. If Indian, All. or Tribe Name
3. Address & Phone No. of Operator PO Box 4289, Farmington, NM 87499 (505) 326-9700	7. Unit Agreement Name
4. Location of Well, Footage, Sec., T, R, M 1890'FNL, 790'FEL Sec.35, T-32-N, R-12-W, NMPM	8. Well Name & Number Moore #5
	9. API Well No.
	10. Field and Pool Glades Frt Sand
	11. County and State San Juan Co, NM

12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTHER DATA

Type of Submission	Type of Action
<input checked="" type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion
<input type="checkbox"/> Final Abandonment	<input type="checkbox"/> Plugging Back
	<input type="checkbox"/> Casing Repair
	<input type="checkbox"/> Altering Casing
	<input type="checkbox"/> Other -
	<input type="checkbox"/> Change of Plans
	<input type="checkbox"/> New Construction
	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Water Shut off
	<input type="checkbox"/> Conversion to Injection

13. Describe Proposed or Completed Operations

It is intended to plug & abandon this well per the attached procedures and wellbore diagram.

RECEIVED
BLM
SEP 9 9 21 AM '92
SEP 9 9 21 AM '92

14. I hereby certify that the foregoing is true and correct.

Signed [Signature] (MP) Title Regulatory Affairs Date 9/9/92

(This space for Federal or State Office use)

APPROVED BY _____ Title _____ Date _____
CONDITION OF APPROVAL, if any:

APPROVED

SEP 11 1992

AREA MANAGER

NMCCD

MOORE #5 FRTS
UNIT H SECTION 35 T32N R12W
San Juan County, New Mexico
P & A Procedure

1. Install & test rig anchors. MI blow tank. MIRUSU. Comply to all NMOC, BLM, & MOI, rules & regulations. Install 2-3/8" relief line. Blow well down. NU 6" BOP and stripping head. Test operation of rams.
2. Pump hot water down both tbq & csg. TOH & lay down 1-1/4" tbq.
3. TIH w/2-7/8" csg scrapper on 1-1/4" tbq to 1100'. TOH.
4. TIH w/2-7/8" cmt ret on 1-1/4" tbq & set @ 1100' (50' above top Ojo Alamo). Pull tbq into test position & pressure test to 2000 psi. Establish rate w/water & sq FRTS perfs w/ 83 sx Cl "B" cmt. This is 100% excess. Max pressure is 2000 psi. Sting out of cmt ret & dump 2 sx cmt on top of ret. TOH & lay down tbq.
5. Perf csg @ 259' (50' below surface csg shoe) w/2 holes. Circ Cl "B" cmt down csg & out bradenhead valve. About 77 sx cmt.
6. Cut off wellhead below surface csg flange and install dry hole marker to BLM specs.
7. Restore location to BLM specs.

Approve: _____
R. F. Headrick

VENDORS:


P&A rig: Bedford 325-1211

PMP

MOORE #5 FRTS

UNIT H SECTION 35 T32N R12W
SAN JUAN COUNTY, NEW MEXICO

PRESENT



MOORE #5 FRTS

UNIT H SECTION 35 T32N R12W
SAN JUAN COUNTY, NEW MEXICO

