

## OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-76

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

RECEIVED

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
N/A	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN A WELL OR TO RE-PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" IF FORM C-103 FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
Union Texas Petroleum Corporation		Culpepper Martin
3. Address of Operator		9. Well No.
P.O. Box 1290 Farmington, New Mexico 87499		1
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <u>P</u> <u>990'</u> FEET FROM THE <u>South</u> LINE AND <u>990'</u> FEET FROM		Blanco Mesaverde
THE <u>East</u> LINE, SECTION <u>31</u> TOWNSHIP <u>32N</u> RANGE <u>12W</u> N.M.P.M.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
5847' KB		San Juan

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set 7" cement retainer @ 4350'
- Sting into retainer at 4350' and squeeze Mesaverde perfs (4548'-4617') with 200 cu.ft. of cement. Sting out of retainer and spot 100' cement plug (23 cu.ft.) above retainer.
- Perforate 7" casing at base of Pictured Cliffs (2400') and spot a 100' inside casing-outside casing cement plug (34 cu.ft.).
- Perforate 7" casing at base of Fruitland (2000') and spot a 100' inside casing-outside casing cement plug (34 cu.ft.).
- Perforate 7" casing at base of Ojo Alamo (1270') and spot a 100' inside casing-outside casing cement plug (34 cu.ft.).
- Perforate 7" casing 50' below surface casing (273') and spot a 100' inside casing-outside casing plug (34 cu.ft.) across surface casing shoe from 173'-273'.
- Spot 50' cement plug (22 cu.ft.) in top of surface casing.
- Clean location and install dry hole marker.

New Mexico Oil Conservation Division will be informed twenty four hours before commencing the above operations.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED W. K. Cooper TITLE Mgr. Dist. Engineering DATE December 9, 1983

Original Signed by CHARLES GHOLSON

DEPUTY OIL & GAS INSPECTOR, DIST. #3

JAN 16 1984

APPROVED BY \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

TITLE \_\_\_\_\_

DATE \_\_\_\_\_