

submitted in lieu of Form 3160-5

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

Sundry Notices and Reports on Wells

1. Type of Well  
GAS

2. Name of Operator  
**BURLINGTON RESOURCES** OIL & GAS COMPANY

3. Address & Phone No. of Operator  
PO Box 4289, Farmington, NM 87499 (505) 326-9700

4. Location of Well, Footage, Sec., T, R, M  
990' FNL, 990' FEL, Sec.33, T-29-N, R-11-W, NMPM

5. Lease Number  
SF-047019-A

6. If Indian, All. or Tribe Name

7. Unit Agreement Name

8. Well Name & Number  
Summit #4

9. API Well No.  
30-045-07725

10. Field and Pool  
Blanco MV/Gallup-DK

11. County and State  
San Juan County, NM

RECEIVED  
JUN - 7 1999  
OIL CON. DIV.  
DIST. 3

12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTHER DATA

Type of Submission	Type of Action
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Abandonment <input type="checkbox"/> Change of Plans
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion <input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment	<input type="checkbox"/> Plugging Back <input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair <input type="checkbox"/> Water Shut off
	<input type="checkbox"/> Altering Casing <input type="checkbox"/> Conversion to Injection
	<input checked="" type="checkbox"/> Other - Tubing Repair

13. Describe Proposed or Completed Operations

It is intended to repair the tubing in the subject well according to the attached procedure.

RECEIVED  
PLM  
99 JUN -2 PM 1:25  
070 FARMINGTON, NM

14. I hereby certify that the foregoing is true and correct.

Signed *Duane W. Spencer* Title Regulatory Administrator Date 6/1/99  
trc

(This space for Federal or State Office use)

APPROVED BY /s/ Duane W. Spencer Title Team Lead, Petroleum Management Date JUN - 4 1999  
CONDITION OF /s/ Duane W. Spencer

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

**Summit #4**  
**Pictured Cliffs**  
**. 990' FNL & 990' FEL**  
**Unit A, Section 33, T29N, R11W**  
**Latitude / Longitude: 36° 41.2079' / 107° 59.4562'**  
**DPNO: 3220201**  
**Tubing Repair Procedure**

**Project Summary:** The Summit #4 was drilled in 1947. The tubing was last pulled 12/83 when the well was re-fraced. We propose to pull the tubing, check for fill and replace any worn or scaled tubing.

1. Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. **Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS.** Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
2. MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow well down and kill with 2% KCL water if necessary. NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
3. The Pictured Cliffs tubing is 1-1/4", IJ J-55 set at 1646' with notched collar and mud anchor on bottom. SN set at 1614'. Release donut, pick up additional joints of tubing and tag bottom (record depth.) PBDT should be at +/- 1740'. TOOH with tubing. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
4. TIH with open ended tubing to below perforations, cleaning out with air/mist. PU above the perforations and flow the well naturally, making short trips for clean up when necessary. TOOH with tubing. **NOTE: When using air/mist, minimum mist rate is 12 bph.**
5. TIH with one joint of 1-1/4" tubing with an expendable check on bottom and a seating nipple one joint off bottom. Run a broach on sandline to insure that the tubing is clear. Land tubing at approximately 1650'. ND BOP and NU WH. Pump off expendable check. Connect to casing and circulate air to assure that expendable check has pumped off. If well will not flow on it's own, make swab run to SN. RD and MOL. Return well to production.

Recommended: Tim Friesenhahn 5-20-99  
Operations Engineer

Approved: Bruce D. Boyer 6-1-99  
Drilling Superintendent

Tim Friesenhahn  
Office - 326-9539  
Pager - 324-7031