

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)


1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Phillips & Spence	8. Farm or Lease Name Martin
3. Address of Operator Unknown	9. Well No. 2
4. Location of Well UNIT LETTER N , 970 FEET FROM THE S LINE AND 1670 FEET FROM THE W LINE, SECTION 34 TOWNSHIP 30-N RANGE 11-W NMPM.	10. Field and Pool, or Wildcat Oswell Farmington
15. Elevation (Show whether DF, RT, GR, etc.)	12. County San Juan

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

7-22-80 Ran 4 3/4 bit to 910 ground level, hit bridge, drill out bridge, bit went to 1050, pump plug # 1 1050 to 950 w/ 15 sks Class "A" Cement, pump plug # 2 @ 700' to 600' w/ 15 sks Class "A" Cement. Perforate 5 1/2 csg @ 600', pump plug # 3 in and outside 600' to 500' w/ 25 sks Class "A" Cement w.o.c. 4 hours tag top cement @ 540' Perforate csg @ 150', set plug # 4 150' to 50' in and outside w/ 25 sks Class "A" Cement, tag top of cement @ 35', pump 10 sks in top and install dry hole marker, fill pits, clean and level location. Ready for inspection.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D. E. Bayle TITLE Porter DATE 7-31-80

APPROVED BY Original Signed by CHARLES GHOLSON DEPUTY OIL & GAS INSPECTOR, DIST. # 5 DATE AUG 4 1980

CONDITIONS OF APPROVAL, IF ANY:

