

GROUND BED ABANDONMENT

WELL NAME: MUDGE LS 6A

LOCATION: S11"C"-TBIN-RIIW

- 1) Weld 6" dia. spool with diverter line to pit
- 2) MIRU
- 3) Wash in hole with 1 1/4" work string. Circulate out coke breeze. Pull anodes as they come free. Wash hole to \* ft. (TD)
- 4) Pump \* sx of neat cement w/ 1/4 lb. sk. Flocele. Pull out work string.
- 5) Top off hole with cement, set flexible pipeline marker as PxA marker.
- 6) RDMO

Ground Bed Specifications

TD \_\_\_\_\_ ft.

Hole Dia. \_\_\_\_\_ inches.

Casing Dia. \_\_\_\_\_ inches

Casing Length \_\_\_\_\_ ft.

UNKNOWN

$$* \text{ SACKS OF CEMENT} = (\text{dia.})^2 \times \text{T.D.} \times .00693$$

WHERE dia. IS IN INCHES

T.D. IS IN FEET

JAB.GRA.