

# R. T. HICKS CONSULTANTS, LTD.

901 Rio Grande Blvd NW ▲ Suite F-142 ▲ Albuquerque, NM 87104 ▲ 505.266.5004 ▲ Since 1996  
Artesia ▲ Carlsbad ▲ Durango ▲ Midland

---

December 27, 2017

Olivia Yu  
NMOCD District 1  
1625 N. French Dr.  
Hobbs, NM 88240

RE: Operator: Pride Energy Company  
NM 87 State #001 (wellhead)  
API#: 30-025-23655  
Section 33-14S-34E: Unit K  
Lea County, New Mexico  
January 11, 2017 Battery Release, Horizontal and Vertical Characterization Plan  
1RP-4624

Dear Ms. Yu:

Hicks Consultants is pleased to submit this proposal on behalf of Pride Energy Company to define the horizontal and vertical extent of the above-referenced historic release. The release occurred prior to Pride Energy's possession of the above referenced location. Figure 1 shows the elevation of groundwater relative to NM 87 State #001. Given the 4,118 elevation of the site and a groundwater elevation of about 4,053; the depth to water at the site is approximately  $(4118-4053=)$  65 feet.

The purpose of this plan is to collect data relating to a historical release at the location, prior to Pride Energy operation, to determine if "a release ... of oil or other water contaminant, in such quantity as may with reasonable probability be detrimental to water or exceed the standards in Subsections A and B or C of 19.15.30.9 NMAC."<sup>1</sup> Pride Energy understands that additional actions may be necessary to supplement the data collected by the program outlined below.

The following actions will be implemented in mid-January 2018. When the schedule is finalized, we will notify OCD and the SLO of the field program at least 48 hours in advance.

1. Prepare a health and safety plan for the proposed actions as well as a detailed sampling and analysis Standard Operating Procedures (SOPs) for submission to OCD and SLO prior to the field program.
2. Based upon
  - physical evidence of the release on the ground,
  - discussions with the pumper, and
  - discussions with the State Land Office,

---

<sup>1</sup> NMAC 19.15.29.8.B

we will conduct trench sampling at the location shown on Figure 2 (SE of the wellhead) that showed a salt crust on the surface during previous site visits by the State Land Office.

3. We will use a backhoe capable of excavating to at least 12 feet to collect samples at 2-foot intervals from the surface to total depth. Total depth will be determined by the backhoe bucket extent (~12ft) or if the backhoe bucket cannot penetrate a hard caliche layer, whichever is less. Soil samples from the trench will be titrated in the field for chloride concentrations. At least two samples from the trench locations showing high chloride titration concentrations and/or showing physical impairment (visual/olfactory) will be submitted to a laboratory for analysis of chloride (Method 300.1), DRO+DRO+MRO extended range (Method 8015M), and BTEX (Method 8260).


We will submit the results of the 1-day field program to OCD and SLO with recommendations for the next step, which could be closure of the regulatory file. Please contact Andrew Parker at 970-570-9535 ([andrew@rthicksconsult.com](mailto:andrew@rthicksconsult.com)) if you have any questions concerning the mid-January 2018 field event.


Sincerely,  
R.T. Hicks Consultants, Ltd.



Andrew Parker  
Env. Project Manager

Copy: Pride Energy  
State Land Office, Ed Martin, Amber Groves





0 20 40  
Feet

R.T. Hicks Consultants, Ltd  
901 Rio Grande Blvd NW Suite F-142  
Albuquerque, NM 87104  
Ph: 505.266.5004

Trench Location	
Pride Energy	
NM 87 State #001 Well Site	

Figure 2
December 2017

# Standard Operating Procedures

---

- Soil Trench Sampling
- Chloride Titration



# R. T. HICKS CONSULTANTS, LTD.

901 Rio Grande Blvd NW ▲ Suite F-142 ▲ Albuquerque, NM 87104 ▲ 505.266.5004 ▲ Since 1996  
Artesia ▲ Carlsbad ▲ Durango ▲ Midland

---

September 3, 2017

## Standard Operating Procedure for Soil Sampling from Test Pits

This document describes the procedures to be used when collecting soil samples using an excavator for the purpose of laboratory analysis. The reader should be familiar with relevant sections of the following document as it is the source of this field method:

Soil Sampling, SESDPROC-300-R3, USEPA, August 2014

<https://www.epa.gov/quality/soil-sampling>

The trenches created by a backhoe or excavator offer the capability of collecting samples from specific intervals and allow visual correlation with vertically and horizontally adjacent material. No sample will be collected by entering a trench deeper than 4 feet.

Data Quality Objectives and Quality Assurance protocols in the sampling plan must be followed. This method must be modified if concentrations of VOCs (e.g. benzene) are expected to be less than 0.2 mg/kg.

This SOP shall be submitted to the excavation contractor at least two work days prior to the scheduled date of sampling.

## Field Method to Collect Samples from Excavator Bucket

1. This SOP is appended to the Health and Safety Plan associated with the field program.
2. Documentation of all sampling is required. Documentation includes, at a minimum
  - a. Photographs of each sample with location stamp on the image or within the electronic file of the photograph
  - b. Written notes in a field notebook that
    - i. Describe the sample in terms of texture, grain size, odor, moisture, color, etc.
    - ii. Correlate the name of the sample with location<sup>1</sup>, depth, photograph number, date and time of sampling
    - iii. Describe any anomalies of sampling (e.g. excessive slough)
    - iv. Provide other useful information (e.g. split samples with others)
  - c. Chain of Custody forms tied to information in the field notebook
3. Inspect the backhoe or excavator to ensure the bucket is clean and free of grease or visual contamination. The intent of this sampling method is to avoid the need to decontaminate the bucket between sampling events.

---

<sup>1</sup> The name of the sample can be a location from a fixed point, such as 120N/30E. The fixed point should be well head, telephone pole, corner of a foundation or other feature that can be easily identified in the field and on a Google Earth image. Latitude and longitude are generally not adequate for sample locations as the accuracy of hand-held GPS can be plus/minus 20 feet. A cemented benchmark may be installed at the site if multiple sampling events are anticipated.

4. Trenches for samples should proceed from the expected cleanest locations to the most impacted locations.
5. Place pre-labeled jars for the expected samples from the trench in a clean sample preparation area covered by a disposable drop cloth, inside the original container box, inside a zip-lock bag, or another secure and suitable protected location.
6. In general, samples should be obtained directly from the bucket in the following manner
  - a. Excavate the sampling trench to form two benches:
    - i. The upper bench is 0.5-1 foot above the proposed depth of sampling
    - ii. The lower bench is 1-2 feet below the upper bench and more distant from the equipment and will capture slough from the excavation and allow the operator to cut into the soil at the upper bench with greater accuracy
  - b. Cause the operator to clean slough from the upper bench and expose the earth material slightly above the desired sampling depth. Direct the operator with hand signals as necessary.
  - c. Direct the operator to remove a 0.5-1 foot layer of earth from the upper bench into the bucket and then to the ground surface
  - d. Examine the earth in the bucket and
    - i. Remove any slough and any smear from the bucket with a clean (decontaminated) trowel or knife to expose relatively undisturbed material
    - ii. Obtain samples of undisturbed material for VOCs (e.g. BTEX) first and non-volatile constituents in a separate container next<sup>2</sup>
    - iii. Do not obtain samples from within 1-inch of the bucket surface
    - iv. Label sample jars for depth and location then place in a cooler on ice in a separate zip-lock bag for each sample suite
    - v. Describe the material in the bucket with respect to grain size, color, odor, texture, etc.
    - vi. Obtain a reasonable close-up photograph of the material
  - e. Inspect the bucket to cause cleaning or decontamination as required to satisfy data quality objectives.
  - f. Dispose of the drop cloth, spilled material or other debris and recondition the sample preparation area with a clean drop cloth and the next set of labeled sample jars.
  - g. Repeat steps a-f for the next sampling depth

Some precision with respect to actual depth of the sample may be reduced with this method but if the soil to be sampled is uniquely distinguishable from the

---

<sup>2</sup> See preservation, container material and sample size requirements on the accompanying chart. The earth material must be packed into a single 2-oz. glass container with a screw cap and septum seal. The sample container must be filled quickly and completely to eliminate head space.

September 3, 2017

Page 3

adjacent or nearby soils, it is possible to adequately characterize the material as to location and depth.

If sampling for low concentrations of VOC (i.e.  $<0.2$  mg/kg of benzene) special sampling containers, samplers and protocols are required.



## **Equipment Checklist**

- Site-specific plans (e.g, Health and Safety and Sampling Plan)
- Plastic zip-top bags to hold samples in cooler
- Field logbook
- Personal protective clothing (see HASP)
- Indelible black ink pens and markers
- Plastic sheeting as drop cloth for sample preparation area and other uses
- Clear, waterproof tape to cover sample labels
- Disposable nitrile or appropriate gloves
- Appropriate sample containers with labels
- Bags of ice
- Decontamination supplies: three buckets, “simple green” soap, Alconox or equivalent, fresh water, distilled water
- Chain of custody forms
- Wipes or paper towels
- Insulated cooler(s)
- Global Positioning System (GPS) unit (iPhone may be acceptable)
- >20-ft measuring tape
- Trash Bags
- Spoons and/or knives that can be completely decontaminated
- Monitoring/screening instruments as required by the health and safety plan

FIELD PROCEDURE  
Chloride Titration Using  
0.282 Normal Silver Nitrate Solution

---

**1.0 Purpose**

This procedure is to be used to determine the concentration of chloride in soil and other solids (e.g. drilling waste).

**2.0 Scope**

This procedure is to be used as the standard field measurement for soil chloride concentrations.

**3.0 Sample Collection and Preparation**

- 3.1 Collect at least 80 grams of soil from the sample collection point. Take care to ensure that the sample is representative of the general area of concern to include visible concentrations of hydrocarbons and soil types. If necessary, prepare a composite sample for soils obtained at several points in the sample area.
- 3.2 The soil sample(s) shall be immediately inserted into a one-quart or larger polyethylene freezer bag. Care should be taken to insure that no cross-contamination occurs between the soil sample and the collection tools or sample processing equipment.
- 3.3 The sealed sample bag should be massaged to break up any clods.

**4.0 Sample Preparation**

- 4.1 Tare a clean glass vial having a minimum 40 ml capacity. Add at least 10 grams of the soil sample and record the weight.
- 4.2 Add at least 10 grams of reverse osmosis water or distilled water to the soil sample and shake or agitate for 20 seconds.
- 4.3 Allow the sample to set for a period of 5 minutes or until the separation of soil and water.
- 4.4 Carefully pour the free liquid extract from the sample, through a paper filter if necessary, into a clean plastic cup.

**5.0 Titration Procedure**

- 5.1 Using a graduated pipette, remove 10 ml extract and dispense into a clean plastic cup.

- 5.2 Add 2-3 drops potassium chromate ( $K_2CrO_4$ ) to mixture.
- 5.3 If the sample contains any sulfides (hydrogen or iron sulfides are common to oilfield soil samples) add 2-3 drops of hydrogen peroxide ( $H_2O_2$ ) to mixture.
- 5.4 Using a 1 ml pipette, carefully add .282 normal silver nitrate (one drop at a time) to the sample while constantly agitating it. Stop adding silver nitrate when the solution begins to change from yellow to red. Be consistent with endpoint recognition.
- 5.5 Record the ml of silver nitrate used.

## 6.0 Calculation

To obtain the chloride concentration, insert measured data into the following formula:

$$\frac{.282 \times 35,450 \times \text{ml AgNO}_3}{\text{ml water extract}} \times \frac{\text{grams of water in mixture}}{\text{grams of soil in mixture}}$$

Using Step 5.0, determine the chloride concentration of the RO water used to mix with the soil sample. Record this concentration and subtract it from the formula results to find the net chloride in the soil sample.

Record all results on a field form.

## Additional Notes

- 1) Make sure the scale is weighing in grams.
- 2) “Zero” the scale with clean, empty 40 ml container (including the cap) sitting on the scale.
- 3) Add 10 to 20 grams of sample soil to the container. Record the weight.
- 4) “Re-zero” the scale.
- 5) Add distilled water to almost fill the container. Record the weight.
- 6) Screw the cap on, and shake the container to thoroughly mix the sample with the distilled water. Set aside to allow settling of the sample. This will take only a few minutes for coarse grained material and up to 20 minutes for very fine grained sediments. The solution does not need to be perfectly clear to continue the procedure.
- 7) Add 3 drops of Potassium Chromate to a small, clean, plastic cup.
- 8) Extract 10 ml (using a large pipette – at least 10 ml) of solution from the sample container and put it into the plastic cup. Record ml of solution placed in the cup.
  - a. This can be kept track of by careful recording of “before” and “after” fluid levels in the pipette.
  - b. Or: Place the plastic cup on the scale with the potassium chromate and “zero” the scale. Add solution to the cup until 10 grams is indicated on the scale.
- 9) Swirl the solution and the potassium chromate to mix them.
- 10) Using a 1 ml pipette, add silver nitrate to the mixed solution drop by drop while swirling. The entire solution will change from a pale lemon yellow color to a brick red color when sufficient silver nitrate has been added. STOP when it all turns brick red. It does not need to be a deep brick red color. This will result in an overly high result. Record ml of silver nitrate used.
- 11) The chloride concentration of the sample is given by:

$$C_{\text{sam}} = (35,450 * 0.282) * \frac{(\text{grams of water})}{(\text{grams of soil})} * \frac{(\text{ml of silver nitrate})}{(\text{ml of solution})}$$

or:

$$C_{\text{sam}} = (9997) * \frac{(\text{grams of water (Step 5)})}{(\text{grams of soil (Step 3)})} * \frac{(\text{ml of silver nitrate (Step 10)})}{(\text{ml of solution (Step 8)})}$$

Units are: mg(of chloride)/kg(of soil)

**Equipment List:**

Scale

10 ml pipettes

1 ml pipettes

Controllers for pipettes (small and large),  
press pipette into open end (carefully)

40 ml sample containers

Small plastic cups

Silver Nitrate

Potassium Chromate

Distilled water

Waste container for final solution. A robust plastic jug with lid will do for field use.

DO NOT pour this down a drain. Dispose of with a chemical lab.

Waste bags for used plastic cups (rinse and pour rinsing fluid into robust jug)

Calculator

Nitrile gloves

Safety glasses

Paper towels

Safety Data

[http://ptcl.chem.ox.ac.uk/~hmc/hsci/chemicals/silver\\_nitrate.html](http://ptcl.chem.ox.ac.uk/~hmc/hsci/chemicals/silver_nitrate.html)

[http://ptcl.chem.ox.ac.uk/~hmc/hsci/chemicals/potassium\\_chromate.html](http://ptcl.chem.ox.ac.uk/~hmc/hsci/chemicals/potassium_chromate.html)