Submit 1 Copy To Appropriate Dist	rict Office	State of No	ew Mexico			Fo	orm C-103		
<u>District I</u> - (575) 393-6161 1625 N. French Dr., Hobbs, NM 882	Energy, 1	Minerals an	d Natural Resources	Revised July 18,2013 WELL API NO.					
<u>District II</u> - (575) 748-1283 811 S. First St., Artesia, NM 88210	OIL C	ONSERVA	ATION DIVISION		30.025. e Type of Lea	.04142			
<u>Disrtict III - (</u> 505) 334-6178	1	1220 South S	St. Francis Dr.		ATE 🔽		EE 🗌		
1000 Rio Brazos Rd. Aztec, NM 87 <u>District IV - (</u> 505) 476-3460		Santa Fe, 1	NM 87505		oil & Gas Leas				
1220 S. St. Francis Dr., Santa Fe, N					B-15				
	DRY NOTICES AND REPOR				Name or Unit	•			
*	PROPOSALS TO DRILL OR DEEP ON FOR PERMIT" (FORM C-101) I				rth Monum	ent G/SA	Unit		
1. Type of Well: Oil Well  Gas Well  Other					8. Well Number 1903				
2. Name of Operator	Anacha Carnarati			9. OGRIE		<b>'</b> 2			
Apache Corporation  3. Address of Operator					873 10. Pool Name or Wildcat				
303 Veteran		Eunice Monument G/SA							
4. Well Location Unit Letter	C : 660	feet from the	N line and	1980	feet from t	W	line		
Section	1 Township	20S	Range 36E	NMPM		County	LEA		
	11. Elevation (Sh		OR, RKB,RT, GR, etc.) 575' GL						
12. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data									
PERFORM REMEDIAL WOR TEMPORARILY ABANDON PULL OR ALTER CASING DOWNHOLE COMMINGLE CLOSED-LOOP SYSTEM	OF INTENTION TO:  RK  PLUG AND ABA CHANGE PLANS MULTIPLE COM	s 🔲	REMEDIAL WORK COMMENCE DRILLING CASING/CEMENT JOB	OPNS.	REPORT ( ALTERING PAND A		6		
OTHER:	1 . 1	<u> </u>	OTHER:	1	. 1	1 1'			
	completed operations. (C	•	_	•		_			
date of starting any proposed work.) SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram or proposed completion or recompletion.									
	oposes to P&A the above Ill fluids from this wellbo		_	-			ystem will		
Spud Date:			Rig Release Date:	Conditi	e Attache		1		
I hereby certify that the information above is true and complete to the best of my knowledge and belief.									
SIGNATURE	Guinn Burks	TITLE	Sr. Reclamation F	oreman	DATE	10/2	22/20		
Type or print name	Guinn Burks	E-mail add.	guinn.burks@apach	ecorp.com	PHONE:	432-5	56-9143		
APPROVED BY:	erry Fortner	TITLE	Compliance Officer	Ą	DATE <u>1</u>	0/30/20			



	WELL BORE INFO.	
		8
0		
•		
	17 1/2" Hole	
	12 1/2" 40# @ 198'	
	w/200 sx to surf	
397		
794		
1191		
1191		
1588		
1985		
	448.11	
2202	11" Hole	
2382	8 5/8" 38# @ 2321' w/ 600 sx to surf	
	Perf'd @ 2425'-2427' sqzd w/ 357 sx CIRC to surf	
	7 617 d @ 2 125 2 127 642d W/ 667 6X 611 to 60 ddi	-
2779		
3176		
	Cal TOC @ 3211'	_
		<b>1</b>

Tubing & TAC @ 3406'

7 7/8" Hole

5 1/2" 17# @ 3820'

w/ 100 sx

4 3/4" Open Hole @ 3820'-3970'

3573

3970

PBTD @ 3695' TD @ 3970'

Perfs @ 3463'-3643'

Perfs @ 3707'-3717', 3770'-3790' CICR @ 3814' sqzd OH w/ 95 sx



LEASE NAME \_ WELL # \_ API #

COUNTY

North Monument Grayburg SA Unit
1903
30.025.04142
LEA

#### PROPOSED PROCEDURE

17 1/2" Hole 12 1/2" 40# @ 198' w/200 sx to surf

397

0

794

1191

1588

1985

2382

2779

3176

0...

3573

7 7/8" Hole 5 1/2" 17# @ 3820' w/ 100 sx Cal TOC @ 3211'

Tubing & TAC @ 3406'

11" Hole

8 5/8" 38# @ 2321'

w/ 600 sx to surf Perf'd @ 2425'-2427' sqzd w/ 357 sx CIRC to surf

3970 4 3/4" Open Hole @ 3820'-3970'

PBTD @ 3695'

TD @ 3970'

4. PUH & spot 35 sx Class "C" cmt from 300' to surf. (Water Board & Surf Shoe)

3. PUH & spot 25 sx Class "C" cmt from 1140'-940', WOC/TAG (Top of Salt)

2. PUH & spot 35 sx Class "C" cmt from 2371' - 2071', WOC/TAG (Base of Salt & Interm Shoe)

1. MIRU P&A rig. POOH & LD tbg. RIH w/WS & verify CIBP @ 3695', CIRC w/MLF & spot 40 sx Class "C" cmt from 3695' -3363', WOC/TAG (Open perfs)

Perfs @ 3463'-3643'

Perfs @ 3707'-3717', 3770'-3790' CICR @ 3814' sqzd OH w/ 95 sx

# CONDITIONS OF APPROVAL FOR PLUGGING AND ABANDONMENT OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify **NMOCD District Office I** (Hobbs) at (575)-263-6633 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down.

## Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private- shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.
- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).

- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
- A) Fusselman
- B) Devonian
- C) Morrow
- D) Wolfcamp
- E) Bone Springs
- F) Delaware
- G) Any salt sections
- H) Abo
- I) Glorieta
- J) Yates.
- K) Potash---(In the R-111-P Area (Potash Mine Area),

A solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, woe 4 hours and tag, this plug will be SO' below the bottom and 50' above the top of the Formation.

21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, woe and tagged. These plugs will be set SO' below formation bottom to 50' above formation top inside the casing

#### DRY HOLE MARKER REQ.UIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

- 1. Operator name
- 2. Lease and Well Number
- 3. API Number
- 4. Unit letter
- 5. Quarter Section (feet from the North, South, East or West)
- 6. Section, Township and Range
- 7. Plugging Date
- 8. County

## SPECIAL CASES ----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)