Submit I Copy To Appropriate District Office		State of New Mexico		Form C-103 Revised August 1, 2011	
<u>District I</u> – (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240 <u>District II</u> – (575) 748-1283	Energy, Minerals and Natural Resources		WELL API NO.	Revised August 1, 2011	
811 S. First St., Artesia, NM 88210 <u>District III</u> – (505) 334-6178				30-015-00957	/
1000 Rio Brazos Rd., Aztec, NM 87410 District IV – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM 87505			5. Indicate Type of Le		
			STATE X 6. State Oil & Gas Lea	FEE /	
				0. State Off & Gas Lea	ise ino.
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A				7. Lease Name or Unit Agreement Name	
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)				Artesia Metex Unit	
1. Type of Well: Oil Well X Gas Well Other				8. Well Number 0053	
2. Name of Operator State of New Mexico formerly Canyon E&P Company DEC 0 5 2018				9. OGRID Number 269864	/
3. Address of Operator 1625 N. French Drive Hobbs, NM 88240 RECEIVED			CEIVED	10. Pool name or Wildcat Artesia QU-GB-SA	
4. Well Location					
Unit LetterN:_	660feet from the	South	line and	_1980feet from the _	Westline
Section 25	Township	18S	Range 27E	NMPM Eddy	County /
	11. Elevation (Show w	hether DR	, RKB, RT, GR, etc.)	
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. P AND A PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMENT JOB					
I hereby certify that the information	•				
SIGNATURE	TIT	LE		DATE	
Type or print name For State Use Only	E-n	nail address	s:		
APPROVED BY: Mall	Kitchen TIT	LE <u>P.</u> E	.5.	DATE_I	2/05/2018

APPROVED BY: Conditions of Approval (if any):

Canyon E&P Company Artesia Metex Unit #53 30-015-00957 660' FSL & 1980 FWL UL-N, Sec 25, T18S, R27E

8 5/8" 24# csg set at 509' with 50 sx cement

Open hole: 509'-2000'

- 1. MIRU and lay down production equipment.
- 2. RIH with tubing and spot 50 sx cement at 1350'
- 3. Tag cement and circulate MLF.
- 4. POOH to 559' and circulate cement to surface.
- 5. Cut off 3' below ground level and verify cement is to surface.
- 6. Install upright marker and cut off anchors.



