

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name
Name of Operator The Maurice L. Brown Company		8. Farm or Lease Name Vada "C"
Address of Operator Suite 200/Sutton Place Bldg./Wichita, Kansas 67202		9. Well No. 3
Location of Well UNIT LETTER B 660 FEET FROM THE North LINE AND 1980 FEET FROM THE East LINE, SECTION 21 TOWNSHIP 9-S RANGE 34-E NMPM.		10. Field and Pool, or Wildcat Vada Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4272' KB		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in and rig up well service unit.
2. Go in hole with bit on tubing and clean out to 1357' (50' below 8 5/8" casing stub).
3. Spot 70 sacks cement through tubing at 1357', to bring top of cement to 1257'.
4. Tag top of cement.
5. Load hole with mud laden fluid.
6. Spot 70 sacks cement through tubing at 425' depth to form 100' plug across 12 3/4" casing shoe at 375' depth.
7. Tag top of cement.
8. Spot 10 sacks cement at surface.
9. Erect dry hole marker.
10. Clean and level location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *Wm. Shoemaker* TITLE District Engineer DATE 9-17-79

APPROVED BY Jerry Sexton TITLE Dist. L. Supv. DATE SEP 21 1979

CONDITIONS OF APPROVAL, IF ANY

RECEIVED

SEP 20 1971

O.C.D. ROBBE, OFFICE