

PROCEDURE - Cont'd  
State '12" Well No. 1

8. RIH w/2-7/8" tbg to 50' below 5-1/2" csg stub & spot 17 sks Class "C" cmt plug. Tag plug. If plug is in place, proceed to step #9. If plug is not in place, spot additional cmt & continue tagging until plug is in place.
9. Pull tbg to 5330' & spot 26 sks Class "C" at the top of the Glorieta.
10. Pull tbg to 4000' & spot 26 sks Class "C" cmt plug across 8-5/8" csg shoe.
11. Pull tbg.
12. Freepoint 8-5/8" csg & cut off (approx 1200').
13. RIH w/2-7/8" tbg to 50' below 8-5/8" csg stub & spot 38 sks Class "C" cmt plug. Tag plug. If plug is in place, proceed to step #14. If plug is not in place, spot additional cmt & continue tagging until plug is in place.
14. Pull tbg to 450' & spot 51 sks Class "C" cmt plug across 11-3/4" csg shoe.
15. Recover 11-3/4" casing head.
16. Run tbg to 20' & spot 10 sks Class "C" cmt plug to surface.
17. Weld 1/2" steel plate on 11-3/4" csg.
18. Rig down csg pullers.
19. Install dry hole marker (Minimum of 4' above ground level). Clean and level location.
20. Obtain final inspection.