

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPlicate*
(Other instructions on reverse side)

Budget Bureau No. 1004-0135
Expires August 31, 1985

RECEIVED
SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

FEB 22 3 41 PM '94

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR HOBBS, INC.

Coastal Oil & Gas Corporation

3. ADDRESS OF OPERATOR

P.O. Box 235, Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)
At surface

Unit F, 1980' FNL & 1980' FWL (SENW)

14. PERMIT NO.

15. ELEVATIONS (Show whether OF, RT, GR, etc.)

GR 3967'

5. LEASE DESIGNATION AND SERIAL NO.

NM 0100236A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

N.M. OIL CONS. COMMISSION

P.O. BOX 1980

HOBBS, NEW MEXICO 88240

8. FARM OR LEASE NAME

Federal "4"

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Sawyer, W. (SA)

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 4, T-10-S, R-37-E

12. COUNTY OR PARISH 13. STATE

Lea

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

NOTE: Set CIBP at 4919' on 7/6/88. Perfs are from 4961'-96' OA.

1. Spot 351 20' cmt plug on top of CIBP (3 sacks).
2. Circ hole with 9.5 PPG mud.
3. Shoot squeeze holes at 3000', 1900' and 465'.
4. GIH and set cmt retainer at 2950', squeeze thru holes at 3000' with 30 sacks. POOH with tbq.
5. GIH and set cmt retainer at 1850', squeeze thru holes at 1900' with 30 sacks. POOH with tbq.
6. Pump down 4-1/2" csg, thru perfs at 468' and back to surface thru annulus. Mix and pump 175 sacks of cmt (30% excess of circulating volume).
7. Install P&A Marker. Clean and level location.

18. I hereby certify that the foregoing is true and correct

SIGNED

Bobby L. Smith
Bobby L. Smith

TITLE Sr. Petroleum Engineer

DATE 2/17/94

(This space for Federal or State office use)

(ORIG. SGD.) JOE G. LARA

APPROVED BY

TITLE PETROLEUM ENGINEER

DATE 3/9/94

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side