

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN THE DATE
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.
LEASE DESIGNATION AND SERIAL NO.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR J.M. Huber Corporation	8. FARM OR LEASE NAME Perry Federal
3. ADDRESS OF OPERATOR 1900 Wilco Bldg., Midland, Texas 79701-4480	9. WELL NO. 1
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 660' FSL, 1980' FEL	10. FIELD AND POOL, OR WILDCAT Prairie San Andres, South
14. PERMIT NO.	11. SEC., T., R., M., OR BLM. AND SURVEY OR AREA Sec. 17-T8S-R36E
15. ELEVATIONS (Show whether DS, RT, GR, etc.) 4125' GR	12. COUNTY OR PARISH Roosevelt
	13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

6/6/84 to 6/10/84 The subject well was plugged and abandoned as follows:

1. Pull pump, rods, and tubing from hole.
2. Set CIBP @ 4900'. Set 5 sks. Class "C" cement on top of plug with dump bailer. (50' of fill) Tag cement @ 4850'.
3. Displace hole with 9.5# salt gel.
4. Pull stretch on 5½" casing to determine freepoint. Free pipe @ 4100'.
5. Shot casing @ 4500'. Pull 100,000#. No movement.
6. Shot casing @ 4300'. Casing pulled loose. Lost wireline in hole.
7. POOH with 4332' of 5½" casing.
8. Spot 30 sks. Class "C" cement plug from 4350' to 4250'.
9. Tag plug @ 4230'.
10. Spot 40 sks. Class "C" cmt. plug from 4230' to 4130'. Waited 5 hrs and tagged plug @ 4113'.
11. Spot 40 sks. Class "C" cmt. plug from 2700' to 2600'. Waited 5 hrs. and tagged plug @ 2580'. (Continued on back)

18. I hereby certify that the foregoing is true and correct

(915) 682-3794

SIGNED Robert R. Glenn Robert R. Glenn TITLE District Production Mgr.DATE June 11, 1984

(This space for Federal or State use)

APPROVED

APPROVED BY: (Orig. Sgd.) PETER W. CHESTER
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

JUL 17 1984

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; kind or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

G.P.O. : 1973-780-622 /V111-148

12. Spot 40 sks. "C" cement from 25.5' to 27.5'. SPOK.
 13. Tagged cement plug @ 2236'.
 14. Cut off 8-5/8" casinghead 3' below ground level.
 15. Set 14 sks. Class "C" cement from 50' to surface.
 16. Install dry hole marker.
 17. Location will be leveled and cleared of junk. Huber
- will notify the BLM when site is ready for inspection.

RECEIVED
JUL 19 1984
O.C.D.
HOBBBS OFFICE