

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE\*  
(Other instructions on re-  
verse side)Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM-0338-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

RECEIVED

1. OIL ☒ GAS ☐ OTHER ☐  
WELL WELL

MAY 4 1976

2. NAME OF OPERATOR

TEXACO Inc.

3. ADDRESS OF OPERATOR

O. C. C.

P. O. Box 728, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface1980' FNL & 1980' FEL, Section 29, T-15-S, R-30-E,  
Unit Letter 'G', Chaves County, New Mexico.

7. UNIT AGREEMENT NAME

Little Lucky Lake Unit

8. FARM OR LEASE NAME

Peery Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Little Lucky Lake Penn  
(shut-in)11. SEC. T. R. M., OR BLK. AND  
SURVEY OR AREA

Sec. 29, T-15-S, R-30-E

14. PERMIT NO.

Regular

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3981' (DF)

12. COUNTY OR PARISH

Chaves

13. STATE

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) Recomplete in Strawn

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any  
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-  
nent to this work.)\*

1. Rig up Unit. Install BOP.
2. Perforate 5½" OD Csg. w/2-JSPF from 9640'-9644'.
3. Run tubing, RBP & packer. Set packer @ 9675'. Spot 250 gal. 15% MCA mud acid over perforations 9640'-9644'. Swab Well. If strawn zone productive proceed w/ Step No. 4.
4. Pull RBP, packer & tubing. Run back w/RBP & retainer. Set RBP @ 8650' & dump sand on top of plug. Set retainer @ 8540'.
5. Squeeze 5½" casing perforations 8561'-8598' w/125 sx. Class 'C' cement w/2% CaCl. Shut-In 24 hrs.
6. Drill out cement & test. Pull RBP.
7. Run packer & RBP. Set RBP @ 9675' & packer @ 9600'.
8. Acidize perforations 9640'-9644'.
9. Test & place on production.

RECEIVED

APR 29 1976

U. S. GEOLOGICAL SURVEY  
ALBUQUERQUE, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Asst. Dist. Supt.

DATE 4-28-76

(This space for Federal or State office use)

APPROVED  
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APR 30 1976  
H. L. BEEKMAN  
ACTING DISTRICT ENGINEER

\*See Instructions on Reverse Side