

Form 9-331
 Dec. 1973

Form Approved.
 Budget Bureau No. 42-R1424

UNITED STATES
 DEPARTMENT OF THE INTERIOR
 GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well gas well other

2. NAME OF OPERATOR
 El Ran, Inc.

3. ADDRESS OF OPERATOR
 P.O. Box 911, Lubbock, Texas 79408

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
 AT SURFACE: Unit Letter ^m 990' FWL & 660' FSL
 AT TOP PROD. INTERVAL: same
 AT TOTAL DEPTH: 4415'

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:	SUBSEQUENT REPORT OF:
TEST WATER SHUT-OFF <input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE <input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES <input type="checkbox"/>	<input type="checkbox"/>
ABANDON* <input checked="" type="checkbox"/>	<input type="checkbox"/>
(other)	

5. LEASE
 NM 13999A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
 Phillips Federal

9. WELL NO.
 #4

10. FIELD OR WILDCAT NAME
 Chaveroo Field 8A

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
 Section 13, T8South, R32East

12. COUNTY OR PARISH
 Chaves

13. STATE
 New Mexico

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)
 4427 G.L.

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Set CIBP at 4200' and spot 35' cement plug on top.
2. Run freepoint and cut casing off and pull 4 1/2 casing.
3. Load hole with 9.5# mud and spot 100' cement plug across the 4 1/2 casing stub. Tag plug.
4. Load hole with 9.5# mud and spot 100' cement plug from 1748' to 1648'. Tag plug.
5. Load hole with 9.5# mud and spot a 50' cement plug at surface.
6. Set marker and back rip location and road.

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Robert R. K... Vice-President DATE 8/13/88

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
 CONDITIONS OF APPROVAL, IF ANY:

APPROVED
 PETER W. CHESTER
 SEP 15 1988
 BUREAU OF LAND MANAGEMENT
 RESOURCE AREA