

Form 9-331
Dec. 1973

Form Approved.
Budget Bureau No. 42-R1424

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well gas well other

2. NAME OF OPERATOR
El Ran, Inc.

3. ADDRESS OF OPERATOR
P.O. Box 911, Lubbock, TX 79408

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: Unit Letter ^N A, 660' FSL & 2280' FWL
AT TOP PROD. INTERVAL: same
AT TOTAL DEPTH: 4409

5. LEASE
NM 13999A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
Phillips Federal

9. WELL NO.
#3

10. FIELD OR WILDCAT NAME
Chaveroo Field SA

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Section 13, T8South, R32East

12. COUNTY OR PARISH
Chaves

13. STATE
N.M.

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)
4440' G.L.

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>		<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>		<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>		<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>		<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>		<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>		<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>		<input type="checkbox"/>
ABANDON*	<input checked="" type="checkbox"/>		<input type="checkbox"/>
(other)			

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Set CIBP at 4225' and spot 35' cement plug on top.
2. Run freepoint and cut casing off and pull 4 1/2 casing.
3. Load hole with 9.5# mud and spot 100' cement plug across the 4 1/2 casing stub. Tag plug.
4. Load hole with 9.5# mud and spot 100' cement plug from 1729' to 1629'. Tag plug.
5. Load hole with 9.5# mud and spot a 50' cement plug at surface.
6. Set marker and back rip location and road.

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Robert R. Ranch TITLE Vice-President DATE 8/13/88

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

APPROVED
PETER W. CHESTER
SEP 15 1988
BUREAU OF LAND MANAGEMENT
RESOURCE AREA

RECEIVED

SEP 22 1988

OCN

HOBBS OFFICE