

**UNITED STATES  
 DEPARTMENT OF THE INTERIOR  
 GEOLOGICAL SURVEY**

**SUNDRY NOTICES AND REPORTS ON WELLS**

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well  gas well  other  Abandon Oil Well

2. NAME OF OPERATOR  
Western Reserves Oil Company

3. ADDRESS OF OPERATOR  
P.O. Box 993, Midland, TX 79702

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
 AT SURFACE: 2300' FSL & 990' Fe1 Sec 10 T-8-S  
 AT TOP PROD. INTERVAL: 3920± R-31-E  
 AT TOTAL DEPTH: 4150

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>		<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>		<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>		<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>		<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>		<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>		<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>		<input type="checkbox"/>
ABANDON*	<input type="checkbox"/>		<input checked="" type="checkbox"/>
(other)	<input type="checkbox"/>		<input type="checkbox"/>

5. LEASE  
NM-19197

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME  
Button Mesa

9. WELL NO.  
1


10. FIELD OR WILDCAT NAME  
Undesignated East Siete San Andres

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
Sec. 10, T-8-S, R-31-E

12. COUNTY OR PARISH | 13. STATE  
Chaves | NM

14. API NO.


15. ELEVATIONS (SHOW DF, KDB, AND WD)  
DF 4324



(NOTE: Report results of multiple completion or zone change on Form 9-330.)  
 U.S. GEOLOGICAL SURVEY  
 ROSWELL, NEW MEXICO

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Set CIBP @ 3834' cap with 2 sx. cement.
2. Set 35 sx. cement plug across 4 1/2' casing stub @ 2325'. Tag this plug @ 2288'.
3. Set 35 sx. cement plug across top of Yates @ 1992'. (2042'-1942')
4. Set 35 sx. cement plug across 8 5/8" casing shoe 1450'. (1400-1500)
5. Set 10 sx. plug @ surface.
6. Install dry hole marker. Clean location.



Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_

18. I hereby certify that the foregoing is true and correct

SIGNED Peter Janice TITLE Agent for WR DATE September 3, 1983

**APPROVED**

(This space for Federal or State office use)

(Orig. Sgd.) PETER W. CHESTER TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

**NOV 8 1984**



RECEIVED BY  
NOV 09 1984  
O. C. D.  
ARTESIA, OFFICE

RECEIVED  
NOV 13 1984  
MOBILE