

NO. COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND FICE	
OPE OR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form O-107  
Supersedes 1111  
6-100 and 2-103  
Effective 1-1-61

<p><b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT ACRYDIP. USE APPLICATION FOR PERMIT - " (FORM O-101) FOR SUCH PROPOSALS.)</p>		<p>1. Indicate type of well State <input checked="" type="checkbox"/> Fee <input type="checkbox"/></p>
<p>2. Name of Operator <b>TEXACO Inc.</b></p>		<p>3. Well No. <b>B-10077</b></p>
<p>3. Address of Operator <b>P.O. Box 728, Hobbs, New Mexico 88240</b></p>		<p>4. Field of Lease <b>New Mexico 'BV' St. (NCT-1)</b></p>
<p>4. Location of Well UNIT LETTER <b>K</b> <b>1981</b> FEET FROM THE <b>South</b> LINE AND <b>1980</b> FEET FROM THE <b>West</b> LINE, SECTION <b>26</b> TOWNSHIP <b>13-S</b> RANGE <b>33-E</b> NMPM.</p>		<p>5. Well No. <b>3</b></p>
<p>5. Elevation (Show whether DF, RT, GR, etc.) <b>4220' DF</b></p>		<p>6. Field and Pool, or Wildcat <b>Lazy J Penn</b></p>
<p>6. County <b>Lea</b></p>		

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
<p>PERFORM REMEDIAL WORK <input type="checkbox"/></p> <p>TEMPORARILY ABANDON <input type="checkbox"/></p> <p>PULL OR ALTER CASING <input type="checkbox"/></p> <p>OTHER <input type="checkbox"/></p>	<p>PLUG AND ABANDON <input checked="" type="checkbox"/></p> <p>CHANGE PLANS <input type="checkbox"/></p> <p>OTHER <input type="checkbox"/></p>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give any other data, to be furnished, to be proposed work) SEE RULE 1103.

1. Pull stuck tubing.
  2. Load hole with mud (25 sx gel per 100 bbls water).
  3. Set CIBP at 9550' and spot 20' (2 sx) cement plug on top. → 35' min. plug required
  4. Ran freepoint, cut 5 1/2" casing and pull.
  5. Spot 100' (20 sx) cement plug across casing stub.
  6. Spot 100' (30 sx) cement plug across intermediate casing shoe at 4065'.
  7. Spot 10' (4 sx) cement plug at surface.
  8. Install marker and clean location.
- 100' plug top Abo  
100' plug top Clavietz  
100' plug top salt* if not behind casing

18. I hereby certify that the information above is true and complete to the best of my knowledge.

SIGNED *John Runyan* TITLE Assistant District Supt. August 4, 1975

APPROVED BY John Runyan Geologist

CONDITIONS OF APPROVAL, IF ANY: