

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

Oct 15 11:01 AM '65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name Lipscomb Estate
9. Well No. 1
10. Field and Pool, or Wildcat Bronco (Wolfcamp)
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Operators Service Company
3. Address of Operator 504 Vaughn Bldg., Midland, Texas
4. Location of Well UNIT LETTER D , 990 FEET FROM THE West LINE AND 330 FEET FROM THE North LINE, SECTION 2 TOWNSHIP T-13-S RANGE R-38-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3804.5' DF

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Estimated Date to Plug - October 19, 1965

2. If no 8-5/8" csg. recovered:

Set cement plugs as follows:

9000 to PBTD 9098'.

25 sx. plug 3500' or in & out of 5-1/2" Stub.

25 sx. plug in & out base of 13-3/8" csg.

10 sx. plug in top of 13-3/8" csg. with appropriate well marker.

Alternate if some 8-5/8" csg. recovered:

Plugs at 9000' to PBTD 9098'

25 sx. in & out of 5-1/2" Stub.

25 sx. in & out of 8-5/8" Stub.

25 sx. in & out of Base of 13-3/8".

10 sx. in top of 13-3/8" with appropriate marker.

3. Salvage all equipment and clean location of all junk, fill all pits & level location.

→ not need if 8 5/8" not pulled

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Curtis C. McDaniel TITLE Engineer DATE 10-14-65

APPROVED BY [Signature] TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: