

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K544	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT - " (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name	
2. Name of Operator Sun Exploration & Production Co.		8. Farm or Lease Name Tenneco "A" State	
3. Address of Operator P. O. Box 1861 - Midland, Texas 79702		9. Well No. 1	
4. Location of Well UNIT LETTER <u>J</u> <u>1874</u> FEET FROM THE <u>East</u> LINE A <u>2086</u> FEET FROM THE <u>South</u> LINE, SECTION <u>8</u> TOWNSHIP <u>14-S</u> RANGE <u>34-E</u> NMPM.		10. Field and Pool, or Wildcat Cerca Upper Penn	
15. Elevation (Show whether DF, RT, GR, etc.)		12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPVS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MIRU csg pulling rig. Load hole w/9.5# mud laden fluid. RIH w/Baker Mod P-1 CIBP on WL and set at 10290'. Dump 4 sx cmt on top of CIBP.
2. Stretch and locate free point of 5½" cst. If free point above 7870', spot 100' cmt plug in 5½" csg from 7972-7872, (Abo top @ 7922). NOTE: Bowen Csg Bowl @485'.
3. Cut off 5½" csg above free point, POH w/5½" csg. Spot 100' cmt plug in and out of csg stub.
4. If free point below 7870, cut off csg and POH. Spot 100' cmt plug in and out of csg stub. Spot 100' cmt plug from 7972-7872.
5. Spot 100' cmt plug in 7-7/8" hole from 5878'-5778', (Glorieta top @ 5828').
6. Spot 100' cmt plug from 4400-4300', (8-5/8 CS @ 4350).
7. Spot 100' cmt plug from 2912'-2812', (btm of salt section-1862').
8. Stretch and locate free point of 8 5/8" csg, cut off above free pt. and POH w/8-5/8" csg. Spot 100' cmt plug in and out of 8-5/8" csg stub.
9. Spot 100' cmt plug from 1903'-1803', (top of salt section-1853').
10. Spot 100' cmt plug from 404'-304' (13-3/8" CS @ 354').
11. Spot 10 sx cmt plug at surface, weld on steel plate, set perm. marker. Clean location.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED De Ann Kemp TITLE Acct. Asst. II DATE 3-8-83

ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT I SUPERVISOR

TITLE

DATE MAR 14 1983

CONDITIONS OF APPROVAL, IF ANY:

**RECEIVED**

**MAR 11 1983**

**G.C.D.  
HOBS OFFICE**