

*Previous Perforation and Plugs:

1. 12,440 to 12,444' (8 holes) Schlumberger plus; plug set @ 12,432'. Cement dumped on top to 12,418.
 2. 12,404 to 12,409' (10 holes) Squeezed with 35 sacks Class "H" with .3% HLX 243 and 1/4# flocele.
 3. 12,064 to 12,072' (5 holes), 12,040 to 12,048' (5 holes) cast iron bridge plug set @ 11,670'. Cement dumped on top to 11,645'.
 4. 11,300 to 11,310' (6 holes), 11,321 to 11,333' (6 holes) cement retainer set @ 10,771'. Squeezed with 50 sacks Class "H".
 5. 10,338 to 10,344' (4 holes) 10,296 to 10,299 (4 holes); 10,256 to 10,262' (4 holes). Cast iron bridge plug set at 10,200'. Dumped cement on top to 10,180'.
 6. 10,113 to 10,118' (6 holes).
- 