

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

**DISTRICT I**  
P.O. Box 1980, Hobbs, NM 88240

**DISTRICT II**  
P.O. Drawer DD, Artesia, NM 88210

**DISTRICT III**  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.  
3002520079

5. Indicate Type of Lease  
STATE  FEE

6. State Oil & Gas Lease No.  
A-3071

7. Lease Name or Unit Agreement Name  
State GG-30

8. Well No.  
2

9. Pool name or Wildcat  
Goodwin Abo

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
OIL WELL  GAS WELL  OTHER

2. Name of Operator  
Mack Energy Corporation

3. Address of Operator  
P. O. Box 960, Artesia, NM 88211-1359 (505) 748-1288

4. Well Location  
Unit Letter M : 660 Feet From The South Line and 660 Feet From The West Line  
Section 30 Township 18-S Range 37-E NMPM Lea, NM County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

<b>NOTICE OF INTENTION TO:</b>		<b>SUBSEQUENT REPORT OF:</b>	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Set 4½ CIBP @ 7725' Cap W/35' cement
- 2) Load hole with mud
- 3) Cut 4½ csg @ 3226' Pull out of hole
- 4) Spot 40 sx cement plug @ 4½ stub @ 3280' W.O.C. Tag cement top @ 3224' Respot 40 sx cement plug @ 3224' W.O.C. Tag cement top @ 3132' this plug also covered the 7-5/8 shoe @ 3200'
- 5) Cut 7-5/8 csg @ 668' pull out of hole
- 6) Spot 25 sx cement plug @ 1704'
- 7) Spot 40 sx cement Plug @ 7-5/8 stub @ 733' W.O.C. Tag cement top @ 606'
- 8) Spot 65 sx cement plug @ 10-3/4 shoe @ 396' W.O.C. Tag cement top @ 290'
- 9) Spot 15 sx cement plug @ surface Set PA marker
- 10) Job completed 1/2/97

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Raymond Maldonado TITLE Operations Supervisor DATE 01/10/97

TYPE OR PRINT NAME \_\_\_\_\_ TELEPHONE NO. \_\_\_\_\_

(This space for State Use)

APPROVED BY Johnny Salinas TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: \_\_\_\_\_