DEPART.	NITED STATES SUBMIT IN TOLICATE DEPART OF THE INTERIOR (Other Instru. 8 on r.) GEOLOGICAL SURVEY			
(Do not use this form for propos Use "APPLICA	CES AND REPORTS O	N WELLS ck to a different reservoir. possis.)	N.M. 020343-	
OIL GAS WELL OTHER	7. UNIT AGREEMENT NAME			
2. NAME OF OPERATOR			8. FARM OR LEASE NAM	<u> </u>
Hanson Oil Corporatio	USA Hanson Federal			
3. ADDRESS OF OPERATOR	9. WELL NO.			
P. O. Box 1515, Roswe	1			
4. LOCATION OF WELL (Report location clease also space 17 below.) At surface	10. PIELD AND POOL, OR WILDCAT			
	660' FSL & 660' FWL		Querecho Plains Yates	
Sec.	11. SEC., T., R., M., OR BI SURVEY OR AREA	K. AND		
	ounty, New Mexico	.*	Sec. 35 - 189	5 - 32E
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, R	T, GR, etc.)	12. COUNTY OR PARISH	
	3708' GL		Lea	N. Mex.
18. Check Ap	propriate Box To Indicate Nat	ture of Notice, Report, or O	ther Data	
NOTICE OF INTENT		INT REPORT OF:		
				

NOTICE OF INTENTION TO:			SUBSEQUENT REPORT OF:			
TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE		PULL OR ALTER CASING MULTIPLE COMPLETE ABANDON®	<u>X</u>	WATER SHUT-OFF REPAIRING WELL FRACTURE TREATMENT ALTERING CASING SHOOTING OR ACIDIZING ABANDONMENT®		
REPAIR WELL (Other)		CHANGE PLANS		(Other) (NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)		
Completion or Recompletion Report and Log form.)						

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

TD @ 4077' PBTD @ 3720' 5-1/2" @ 3810' w/250 sx.

Perfs. @ 3344-3678'

8-5/8" @ 1419' w/625 sx.

It is proposed to plug and abandon the captioned well in the following manner:

- 1. Displace hole with heavy mud.
- 2. Spot a 25 sx. cement plug @ 3344' across perfs.
- 3. Cut and recover as much 5-1/2" casing as possible.
- 4. Spot a 25 sx. cement plug in-and-out of 5-1/2" casing scub.
- 5. Spot a 25 sx. cement plug in-and-out of 8-5/8" casing shoe @ 1419'.
- 6. Spot a 10 sx. cement plug at the surface and erect a regulation dry hole marker.
- 7. Clean up location for final U.S.G.S. inspection.

Verbal permission to plug was given by USGS @ Hobbs.

8. I hereby certify that the foregoing is true and correct	
SIGNED Harry J. Schram	TITLE Exec. Vice President DATE 8-20-
(This space for Federal or State office use) APPROVED BY CONDITIONS OF APPROVAL, IF ANY:	APPROVED TATE
	SEP 2 1970
*S	See Instructions on Reverse Bide RICT ENGINEER DISTRICT ENGINEER