

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-7

5a. Indicate Type of Lease  
State  Fed   
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO REPERF OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE APPLICATION FOR PERMIT TO DRILL (FORM C-101) FOR SUCH PROPOSALS.

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Amoco Production Company	8. Farm or Lease Name South Hobbs (GSA) Unit
3. Address of Operator P. O. Box 68, Hobbs, New Mexico 88240	9. Unit No. 46
4. Location of well UNIT LETTER <u>L</u> <u>1980</u> FEET FROM THE <u>South</u> <u>660</u> FEET FROM THE <u>West</u> <u>3</u> LINE, SECTION <u>19-S</u> TOWNSHIP <u>38-E</u> RANGE <u>38-E</u> N.M.P.M.	10. Field and Pool, or adjacent Hobbs GSA
15. Elevation (Show whether DF, RT, CR, etc.) 3612' DF	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK   
TEMPORARILY ABANDON   
PULL OR ALTER CASING   
OTHER

PLUG AND ABANDON   
CHANGE PLANS   
OTHER

SUBSEQUENT REPORT OF:

REMEDIAL WORK   
COMMENCE DRILLING OPMS.   
CASING TEST AND CEMENT JOBS   
OTHER   
ALTERING CASING   
PLUG AND ABANDONMENT

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to squeeze off water productive zone I and perforate additional pay as follows:

Pull rods, pump, and tubing. Plug back from TD to 4114' with sand and set a cast iron bridge plug on top of sand. Set a packer at apx. 4070' and establish injection rate into perfs. If there is communication, pull packer and set a cement retainer at 4070'. Cement squeeze with 50 sacks class "C" neat cement followed by 200 sacks class "C" with 5 lbs Gilsonite/sack of cement. Tail in with 200 sacks class "C" neat cement. Drill out cement retainer and cement to cast iron bridge plug. Pressure test squeeze. Drill out cast iron bridge plug and sand to 4240'. Clean up and displace wellbore with filtered lease water. Perforate 3973'-81', 87'-90', 96'-98', 4000'-06', 09'-27', 50'-64', 4136'-50', and 85'-90' with 4 SPF. Run tubing, rods, and pump. Install beam unit. Return well to production.

0+4-NMOCD,H 1-HOU 1-SUSP 1-CLF

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cathy L. Forman

TITLE Assist. Admin. Analyst

DATE 1-20-83

ORIGINAL SIGNED BY  
EDDIE W. SEAY

APPROVED BY

TITLE

DATE

JAN 24 1983

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JAN 21 1983

O.C.D.  
HOBBS OFFICE