

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

CONDRIY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" FORM C-1011 FOR SUCH PROPOSALS.)

5a. Indicate Type of Lease
State Fee
5. State Oil & Gas Lease No.

6. Unit Agreement Name
7. Name of Operator
8. Form or Lease Name
9. Well No.
10. Field and Pool, or offset

OIL WELL GAS WELL OTHER

Name of Operator: **AMOCO PRODUCTION COMPANY**

Address of Operator: **P. O. Box 68, Hobbs, NM 88240**

Location of well:
UNIT LETTER **X** **660** FEET FROM THE **East** LINE AND **660** FEET FROM
THE **South** LINE, SECTION **2** TOWNSHIP **21-S** RANGE **36-E** NMPM.

7. Unit Agreement Name
8. Form or Lease Name
9. Well No.
10. Field and Pool, or offset
12. County

State "C" Tr. 11
1
Eunice Monument
Lea

15. Elevation (Show whether DF, RT, GR, etc.)
3527' GL

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input checked="" type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
WELL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to squeeze Eumont and drill out to total depth and turn well over to Chevron. MI and RUSU. Kill well. RIH with cement retainer for 7" 22# casing and set at appx. 2550. Cement squeeze well and pmp 2000 sacks class C cement with fluid loss additive. Pump 100 sacks of class C cement (neat). Displace with 14 BW. WO cement overnight then start drilling out cement to 3610. Pressure test the cement squeeze to 500# at following depths: 2770, 3110, 3270, 3430 and 3610. Once squeeze holds then drill out to TD at 3854. RD and MOSU. Turn wellbore over to Chevron.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

by S. Brownlee TITLE Administrative Analyst DATE 2-2-87

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE FEB 5 1987

CONDITIONS OF APPROVAL, IF ANY: